



# USER INSTRUCTIONS

## 3400IQ Digital Positioner

FCD LGENIM3401-00 – 06/06

*Installation  
Operation  
Maintenance*



*Experience In Motion*


# Contents


1	Terms Concerning Safety	4
2	General Information	4
3	Unpacking and Storage	5
3.1	Unpacking	5
3.2	Storage	5
3.3	Pre-installation Inspection	7
4	Logix 3400/Q Positioner Overview	7
4.1	Specifications	10
4.2	Positioner Operation	11
4.3	Detailed Sequence of Positioner Operations	12
5	Mounting and Installation	14
5.1	Mounting to Valtek Linear Mark One Valves	14
5.2	Mounting to Standard Valtek Rotary Valves (See Figure 4)	15
5.3	Optional Valtek Rotary Mounting Procedure (See Figure 5)	17
5.4	NAMUR Mounting Option	18
5.5	Tubing Positioner to Actuator	18
6	Wiring and Grounding Guidelines (See Figure 6)	19
6.1	FF Command Input Wiring	19
6.2	Grounding Screw	19
6.3	Segment Compliance Voltage (See Figure 7)	20
6.4	Cable Requirements	21
6.5	Intrinsically Safe Barriers	21
6.6	DD Support	21
7	Startup	22
7.1	Logix 3400/Q Local Interface Operation	22
7.2	Initial DIP Switch Settings	22
7.3	Description of Configuration DIP Switch Settings	23
7.4	Description of Cal DIP Switch Settings	26
7.5	RE-CAL Operation	26
7.6	Manual Jog Calibration Operation	27
7.7	Local Control of Valve Position	27
7.8	Factory Reset	27
7.9	Logix 3400/Q Status Condition	27
7.10	Version Number Checking	30
7.11	375 Handheld Communicator	31
7.12	Device Description (DD) Files	31
7.13	Calibration	31
2	7.13.1 CALIBRATE_FLAGS	31
	7.13.2 Control and Tuning	32


7.14	Alerts	35
7.14.1	FINAL_VALUE_CUTOFF	35
7.14.2	Effects of FINAL_VALUE_CUTOFF on Operation	35
7.14.3	Soft Limits	35
7.14.4	Travel Accumulator	35
7.14.5	Cycle Counter	36
7.14.6	Position Deviation	36
7.14.7	Advanced Features	36
7.14.8	Standard vs. Advanced Diagnostics	36
7.14.9	Temperature and Pressure Units	36
7.14.10	Stroke Length	37
7.15	Characterization Retention	38
7.15.1	Initiating a Valve Signature	38
7.15.2	System Preparation	38
7.15.3	Signature Procedure	38
7.16	Step Signature	39
7.16.1	Collection of Stored Signature	39
7.17	Glossary	39
7.18	Transducer Block Parameters	41
8	Maintenance and Repair	50
8.1	Driver Module Assembly	50
8.2	Regulator	54
8.3	Checking or Setting Internal Regulator Pressure	55
8.4	Spool Valve	57
8.5	Spool Valve Cover	58
8.6	Stem Position Sensor	59
8.7	Main PCB Assembly	60
8.8	Pressure Sensor Board	61
8.9	User Interface Board	63
9	Optional Vented Design	64
10	Parts List	67
11	Logix 3400IQ Spare Parts Kits (See Figure 22 for item numbers)	68
12	Logix 3400IQ Mounting Kits	70
12.1	Valtek Mounting Kits	70
12.2	Logix O.E.M. Mounting Kits	71
12.3	NAMUR Accessory Mounting Kit Part Numbers	73
13	Frequently Asked Questions	74
14	How to Order	75
15	Troubleshooting	76

# 1 Terms Concerning Safety

The safety terms DANGER, WARNING, CAUTION and NOTE are used in these instructions to highlight particular dangers and/or to provide additional information on aspects that may not be readily apparent.

 **DANGER:** Indicates that death, severe personal injury and/or substantial property damage will occur if proper precautions are not taken.

 **WARNING:** Indicates that death, severe personal injury and/or substantial property damage can occur if proper precautions are not taken.

 **CAUTION:** Indicates that minor personal injury and/or property damage can occur if proper precautions are not taken.

**NOTE:** indicates and provides additional technical information, which may not be very obvious even to qualified personnel. Compliance with other, not particularly emphasized notes, with regard to transport, assembly, operation and maintenance and with regard to technical documentation (e.g., in the operating instruction, product documentation or on the product itself) is essential, in order to avoid faults, which in themselves might directly or indirectly cause severe personal injury or property damage.


# 2 General Information

The following instructions are designed to assist in unpacking, installing and performing maintenance as required on Flowserve Valtek Logix® 3400IQ digital positioners. Series 3000 is the term used for all the positioners herein; however, specific numbers indicate features specific to model (i.e., Logix 3400 indicates that the positioner has FOUNDATION Fieldbus protocol). See Logix 3400IQ Model Number table in this manual for a breakdown of specific model numbers. Product users and maintenance personnel should thoroughly review this bulletin prior to installing, operating, or performing any maintenance on the valve.

Separate Valtek Flow Control Products Installation, Operation, Maintenance instructions cover the valve (such as IOM 1 or IOM 27) and actuator (such as IOM 2 or IOM 31) portions of the system and other accessories. Refer to the appropriate instructions when this information is needed.

To avoid possible injury to personnel or damage to valve parts, WARNING and CAUTION notes must be strictly followed. Modifying this product, substituting non-factory parts or using maintenance procedures other than outlined could drastically affect performance and be hazardous to personnel and equipment, and may void existing warranties.


4

 **WARNING:** Standard industry safety practices must be adhered to when working on this or any process control product. Specifically, personal protective and lifting devices must be used as warranted.

## 3 Unpacking and Storage

### 3.1 Unpacking

1. While unpacking the Logix 3400IQ positioner, check the packing list against the materials received. Lists describing the system and accessories are included in each shipping container.
2. When lifting the system from the shipping container, position lifting straps to avoid damage to mounted accessories. Systems with valves up to six inches may be lifted by actuator lifting ring. On larger systems, lift unit using lifting straps or hooks through the yoke legs and outer end of body.

 **WARNING:** When lifting a valve/actuator assembly with lifting straps, be aware the center of gravity may be above the lifting point. Therefore, support must be given to prevent the valve/actuator from rotating. Failure to do so can cause serious injury to personnel or damage to nearby equipment.

3. In the event of shipping damage, contact the shipper immediately.
4. Should any problems arise, contact a Flowserve Flow Control representative.


### 3.2 Storage

Control valve packages (a control valve and its instrumentation) can be safely stored in an enclosed building that affords environmental protection; heating is not required. Control valve packages must be stored on suitable skids, not directly on the floor. The storage location must also be free from flooding, dust, dirt, etc.

#### **Long Term Storage of Logix 3000 series Positioners in Humid Locations**

The Logix 3000 series positioners are designed to operate in humid environments when connected to a proper instrument air supply. There are some occasions when valves and positioners are stored at job sites or installed and commissioned and then left without instrument air for months. To make startup easier for units that are left without instrument air and insure that the positioners will be ready to operate, it is recommended that the vent assembly of the positioner be sealed preferably with a desiccant pouch sealed with the vent assembly.

The vent assembly is located in the upper left side of the positioner. The gaps around the assembly as noted by the arrows should be sealed for long term storage.



A small desiccant package as shown can be included under the sealing tape to insure proper protection.



All of the edges around the vend assembly should be sealed similar to the picture below.



The sealing tape and desiccant should be removed when instrument air is permanently applied to the positioner.

### 3.3 Pre-installation Inspection

If a valve control package has been stored for more than one year, inspect one actuator by disassembling it per the appropriate Installation, Operation, and Maintenance Instructions (IOM) prior to valve installation. If O-rings are out-of-round, deteriorated, or both, they must be replaced and the actuator rebuilt. All actuators must then be disassembled and inspected. If the actuator O-rings are replaced, complete the following steps:

1. Replace the pressure-balance plug O-rings.
2. Inspect the solenoid and positioner soft goods and replace as necessary.

## 4 Logix 3400IQ Positioner Overview

The Logix 3400IQ digital positioner is a two-wire FOUNDATION Fieldbus compliant digital valve positioner. The positioner is configurable through the local user interface. The Logix 3400IQ utilizes the FF protocol to allow two-way remote communications with the positioner. The Logix 3400IQ positioner can control both double- and single-acting actuators with linear or rotary mountings. The positioner is completely powered by the FF signal. Start up voltage must be from a FF power supply source.

Figure 1: Logix 3400IQ Digital Positioner Schematic (air-to-open configuration)







Figure 2: System Positioning Algorithm



## 4.1 Specifications

*Table I: Electrical Specifications*

Power Supply	Two-wire, 9-32 VDC FF compatible
IS	Fisco compliant
Communications	FF Protocol ITK 4.6x
Operating Current	23 mA
Maximum Voltage	36.0 VDC

*Table II: Environmental Conditions*

Operating Temperature Range	Standard	-40° to 176°F
		(-40° to 80°C)
Transport and Storage Temperature Range	-40° to 176°F (-40° to 80°C)	
Operating Humidity	0 - 100% non-condensing	

*Note: The air supply must conform to ISA Standard ISA 7.0.01 (a dew point at least 18 degrees Fahrenheit below ambient temperature, particle size below five microns—one micron recommended—and oil content not to exceed one part per million).*

*Table III: Physical Specifications*

Housing Material	Cast, powder-painted aluminum, stainless steel
Soft Goods	Buna-N / Florosilicone
Weight	8.3 pounds (3.9 kg) aluminum 20.5 pounds (9.3 kg) stainless steel

*Table IV: Positioner Specifications*

Deadband	<0.1% full scale
Repeatability	<0.05% full scale
Linearity	<0.5% (rotary), <0.8%, (sliding stem) full scale
Air Consumption	<0.3 SCFM (0.5 Nm <sup>3</sup> /hr) @ 60 psi (4 bar)
Air Supply	30-150 psig (ISA 7.0.0.1 compliant)

Table V: Hazardous Area Certifications

Intrinsically Safe <b>(PENDING)</b>	Explosion Proof Ⓢ Approved
Class I, Div 1, Groups A, B, C, D Class II, III, Div 1, Groups E, F, G (See Figure 1 for installation requirements.)	Class I, Div 1, Groups B, C, D Class II, III, Div 1, Groups E, F, G T6 Ta = 60°C NEMA/TYPEx 4X
Intrinsically Safe <b>(PENDING)</b>	Ⓢ II 1G EEx ia IIC T4, T5 T4 Ta = -40°C to 80°C T5 Ta = -40°C to 35°C IP 65
Flameproof <b>(PENDING)</b>	Ⓢ II 2 GD EEx d IIB + H2 T5, Ta = -40°C to 80°C IP65
CE Compliant	
FISCO Compliant	

## 4.2 Positioner Operation

The Logix 3400IQ positioner is an electric feedback instrument. Figure 1 shows a Logix 3400IQ positioner installed on a double-acting linear actuator for air-to-open action.

The Logix 3400IQ receives power from the two-wire, FF input signal. This positioner utilizes FF communications for the command signal. The command source can be accessed with the Rosemount 375 communicator or other host software.

0% is always defined as the valve closed position and 100% is always defined as the valve open position. During stroke calibration, the signals corresponding to 0% and 100% are defined.

The input signal in percent passes through a characterization/limits modifier block. The positioner no longer uses CAMs or other mechanical means to characterize the output of the positioner. This function is done in software, which allows for in-the-field customer adjustment. The positioner has four basic modes: *Linear*, *Equal Percent (=%)*, *Quick Open (QO)* and *Custom* characterization. In *Linear* mode, the input signal is passed straight through to the control algorithm in a 1:1 transfer. In *Equal Percent (=%)* mode, the input signal is mapped to a standard 30:1 rangeability =% curve. In *Quick Open* the input signal is mapped to an industry standard quick-open curve. If *Custom* characterization is enabled, the input signal is mapped to either a default =% output curve or a custom, user-defined 21-point output curve. The custom user-defined 21-point output curve is defined using a handheld or the Host configuration tool software. In addition, two user-defined features, *Soft Limits* and *Final Value Cutoff*, may affect the final input signal. The actual command being used to

position the stem, after any characterization or user limits have been evaluated, is called the *Control Command*.

The Logix 3400IQ uses a two-stage, stem-positioning algorithm. The two stages consist of an inner-loop, spool control and an outer-loop, stem position control. Referring again to Figure 1, a stem position sensor provides a measurement of the stem movement. The *Control Command* is compared against the *Stem Position*. If any deviation exists, the control algorithm sends a signal to the inner-loop control to move the spool up or down, depending upon the deviation. The inner-loop then quickly adjusts the spool position. The actuator pressures change and the stem begins to move. The stem movement reduces the deviation between *Control Command* and *Stem Position*. This process continues until the deviation goes to zero.

The inner-loop controls the position of the spool valve by means of a driver module. The driver module consists of a temperature-compensated hall effect sensor and a piezo valve pressure modulator. The piezo valve pressure modulator controls the air pressure under a diaphragm by means of a piezo beam bender. The piezo beam deflects in response to an applied voltage from the inner-loop electronics. As the voltage to the piezo valve increases, the piezo beam bends, closing off against a nozzle causing the pressure under the diaphragm to increase. As the pressure under the diaphragm increases or decreases, the spool valve moves up or down respectively. The hall effect sensor transmits the position of the spool back to the inner-loop electronics for control purposes.

### 4.3 Detailed Sequence of Positioner Operations

A more detailed example explains the control function. Assume the unit is configured as follows:

- Unit is in *OOS*.
- *Custom* characterization is disabled (therefore characterization is *Linear*).
- No soft limits enabled. No Final Value Cutoff set.
- Valve has zero deviation with a present input command of 50.
- Write to Final\_Value to change command.
- Actuator is tubed and positioner is configured air-to-open.


Given these conditions, 50 represents a *Command source* of 50 percent. *Custom characterization* is disabled so the *Command source* is passed 1:1 to the *Control Command*. Since zero deviation exists, the *Stem Position* is also at 50 percent. With the stem at the desired position, the spool valve will be at a middle position that balances the pressures above and below the piston in the actuator. This is commonly called the *null* or *balanced* spool position.

Assume the input signal changes from 50 to 75. The positioner sees this as a *Command source* of 75 percent. With *Linear characterization*, the *Control Command* becomes 75 percent. Deviation is the difference between *Control Command* and *Stem Position*:  $\text{Deviation} = 75\% - 50\% = +25\%$ , where 50 percent is the present stem position. With this positive deviation, the control algorithm sends a signal to move the spool up from its present position. As the spool moves up, the supply air is applied to the bottom of the actuator and air is exhausted from the top of the actuator. This new pressure differential causes the stem to start moving towards the desired position of 75 percent. As

the stem moves, the *Deviation* begins to decrease. The control algorithm begins to reduce the spool opening. This process continues until the *Deviation* goes to zero. At this point, the spool will be back in its null or balanced position. Stem movement will stop and the desired stem position is now achieved.

One important parameter has not been discussed to this point: Inner loop offset. Referring to Figure 2, a number called *Inner loop offset* is added to the output of the control algorithm. In order for the spool to remain in its null or balanced position, the control algorithm must output a non-zero spool command. This is the purpose of the *Inner loop offset*. The value of this number is equivalent to the signal that must be sent to the spool position control to bring it to a null position with zero deviation. This parameter is important for proper control and is optimized and set automatically during stroke calibration.

Figure 3: Linear Mark One Control Valve Mounting



## 5 Mounting and Installation

### 5.1 Mounting to Valtek Linear Mark One Valves


To mount a Logix 3400IQ positioner to a Valtek linear Mark One valve, refer to Figure 3 and proceed as outlined below. The following tools are required:

- $\frac{9}{16}$ " open-end wrench (or  $\frac{1}{2}$ " for spud sizes 2.88 and smaller)
  - $\frac{7}{16}$ " box wrench
  - $\frac{3}{8}$ " open-end wrench
1. Remove washer and nut from follower pin assembly. Insert pin into the appropriate hole in follower arm, based on stroke length. The stroke lengths are stamped next to their corresponding holes in the follower arms. Make sure the unthreaded end of the pin is on the stamped side of the arm. Reinstall lock washer and tighten nut to complete follower arm assembly.
  2. Slide the double-D slot in the follower arm assembly over the flats on the position feedback shaft in the back of the positioner. Make sure the arm is pointing toward the customer interface side of the positioner. Slide lock washer over the threads on the shaft and tighten down the nut.
  3. Align the bracket with the three outer mounting holes on the positioner. Fasten with  $\frac{1}{4}$ " bolts.
  4. Screw one mounting bolt into the hole on the yoke mounting pad nearest the cylinder. Stop when the bolt is approximately  $\frac{3}{16}$ " from being flush with mounting pad.
  5. Slip the large end of the teardrop shaped mounting hole in the back of the positioner/bracket assembly over the mounting bolt. Slide the small end of the teardrop under the mounting bolt and align the lower mounting hole.
  6. Insert the lower mounting bolt and tighten the bolting.
  7. Position the take-off arm mounting slot against the stem clamp mounting pad. Apply Loctite 222 to the take-off arm bolting and insert through washers into stem clamp. Leave bolts loose.
  8. Slide the appropriate pin slot of the take-off arm, based on stroke length, over the follower arm pin. The appropriate stroke lengths are stamped by each pin slot.
  9. Center the take-off arm on the rolling sleeve of the follower pin.
  10. Align the take-off arm with the top plane of the stem clamp and tighten bolting. Torque to 120 in-lb.

**NOTE:** If mounted properly, the follower arm should be horizontal when the valve is at 50% stroke and should move approximately  $\pm 30^\circ$  from horizontal over the full stroke of the valve. If mounted incorrectly, a stroke calibration error will occur and the indicator lights will blink a YRRY or YRRY code indicating the position sensor has gone out of range on one end of travel. Reposition the feedback linkage or rotate the position sensor to correct the error.

## 5.2 Mounting to Standard Valtek Rotary Valves (See Figure 4)

Figure 4: Standard Rotary Mounting



The standard rotary mounting applies to Valtek valve/actuator assemblies that do not have mounted volume tanks or handwheels. The standard mounting uses a linkage directly coupled to the valve shaft. This linkage has been designed to allow for minimal misalignment between the positioner and the actuator. The tools required for the following procedure are:

- 5/32" Allen wrench
- 1/2" open-end wrench
- 7/16" open-end wrench
- 3/8" socket with extension
- 3/16" nutdriver

1. Fasten the spline lever adapter to the splined lever using two 6 x 1/2" self-tapping screws.
2. Slide the take-off arm assembly onto the spline lever adapter shaft. Insert the screw with star washer through the take-off arm and add the second star washer and nut. Tighten nut with socket so arm is lightly snug on the shaft but still able to rotate. This will be tightened after linkage is correctly oriented.
3. Attach follower arm to positioner feedback shaft using the star washer and 10-32 nut.

**NOTE:** The arm will point up when feedback shaft is in the free position.

4. Using four ¼-20 x ½" bolts, fasten positioner to universal bracket using appropriate hole pattern (stamped on bracket).
5. Using a ½" end wrench and two 5/16-18 x ½" bolts, attach bracket to actuator transfer case pad. Leave these bolts slightly loose until final adjustments are made.
6. Rotate take-off arm so the follower pin will slide into the slot on the take-off arm. Adjust the bracket position as needed noting the engagement of the follower pin and the take-off arm slot. The pin should extend approximately ¼" past the take-off arm. When properly adjusted, securely tighten the bracketing bolts.

#### **Orienting the Take-off Arm for Final Lock Down**

1. Tube the Logix 3400IQ positioner to the actuator according to the instructions given in Section 5.5, "Tubing Positioner to Actuator."
2. **With supply pressure off**, rotate the follower arm in the same direction the shaft would rotate upon a loss of supply pressure. When the mechanical stop of the follower arm (positioner) is reached, rotate back approximately 15 degrees.

3. Hold the take-off arm in place; tighten the screw of the take-off arm.

**NOTE:** The take-off arm should be snug enough to hold the follower arm in place but allow movement when pushed.

4. Connect regulated air supply to appropriate port in manifold.
5. Remove main cover and locate DIP switches and RE-CAL button.
6. Refer to sticker on main board cover and set DIP switches accordingly. (A more detailed explanation of the DIP switch settings is given in Section 7, "Startup.")
7. Press the RE-CAL button for three to four seconds or until the positioner begins to move. The positioner will now perform a stroke calibration.
8. If the calibration was successful the green LED will blink GGGG or GGGY and the valve will be in control mode. Continue with step 9. If calibration failed, as indicated by a YRYR or YRRY blink code, the A/D feedback values were exceeded and the arm must be adjusted away from the positioners limits. Return to step 2 and rotate the arm back approximately 10 degrees.

**NOTE:** Remember to remove the air supply before re-adjusting take-off arm.

9. Tighten the nut on the take-off arm. The socket head screw of the take-off arm must be tight, about 40 in-lb.


**NOTE:** If the take-off arm slips, the positioner must be recalibrated.



- ⚠ **WARNING:** Failure to follow this procedure will result in positioner and/or linkage damage. Check air-action and stroke carefully before lockdown of take-off arm to spline lever adapter.

### 5.3 Optional Valtek Rotary Mounting Procedure (See Figure 5)

Figure 5: Optional Rotary Mounting




The optional rotary mounting applies to Valtek valve/actuator assemblies that are equipped with mounted volume tanks or handwheels. The optional mounting uses a four-bar linkage coupled to the valve shaft. The following tools are required:

- 3/8" open-end wrench
- 7/16" open-end wrench
- 1/2" open-end wrench

1. Using a 1/2" open-end wrench and two 5/16-18 x 1/2" bolts, attach bracket to actuator transfer case pads. Leave bracket loose to allow for adjustment.

- Using four ¼-20 x ½" bolts and a 7/16" open-end wrench, fasten positioner to universal bracket, using the four-hole pattern that locates the positioner the farthest from the valve. Rotate positioner 90 degrees from normal so gauges are facing upward.
- Attach follower arm to positioner feedback shaft, using the star washer and 10-32 nut.
- Attach tripper and tripper clamp to valve shaft using two ¼-20 bolts and two ¼-20 locknuts. Leave tripper loose on shaft until final adjustment.
- Thread ball joint linkage end to tripper and tighten (thread locking compound such as Loctite is recommended to prevent back threading). Adjust the length of tie rod so follower arm and tripper rotate parallel to each other (the rod must be cut to the desired length). Connect the other ball joint end to follower arm using a star washer and a 10-32 nut.
- Tighten bracket and tripper bolting.
- Check for proper operation, note direction of rotation.

 **WARNING:** If rotating in wrong direction, serious damage will occur to the positioner and/or linkage. Check air action and stroke direction carefully before initiating operation.

## 5.4 NAMUR Mounting Option

Logix 3200IQ is available with a NAMUR output shaft and mounts on an actuator using the ISO F05 holes. Proper alignment of the positioner shaft to the actuator shaft is very important since improper alignment can cause excess wear and friction to the positioner.

## 5.5 Tubing Positioner to Actuator

The Logix 3400IQ digital positioner is insensitive to supply pressure changes and can handle supply pressures from 30 to 150 psig. A supply regulator is recommended if the customer will be using the diagnostic features of the Logix 3400IQ but is not required. In applications where the supply pressure is higher than the maximum actuator pressure rating a supply regulator is required to lower the pressure to the actuator's maximum rating (not to be confused with operating range). An air filter is highly recommended for all applications where dirty air is a possibility.

**NOTE:** The air supply must conform to ISA Standard ISA 7.0.01 (a dew point at least 18°F below ambient temperature, particle size below five microns—one micron recommended—and oil content not to exceed one part per million).

Air-to-open and air-to-close are determined by the actuator tubing, not the software. When air action selection is made during configuration, that selection tells the control which way the actuator has been tubed. The top output port is called *Output 1*. It should be tubed to the side of the actuator that must receive air to begin the correct action on increasing signal. Verify that tubing is correct prior to a stroke calibration. Proper tubing orientation is critical for the positioner to function correctly and have the proper failure mode. Refer to Figure 1 and follow the instructions below:

### Linear Double-acting Actuators

For a linear air-to-open actuator, the Output 1 port of the positioner manifold is tubed to the bottom side of the actuator. The Output 2 port of the positioner manifold is tubed to the top side of the actuator. For a linear air-to-close actuator the above configuration is reversed.


### Rotary Double-acting Actuators

For a rotary actuator, the Output 1 port of the positioner manifold is tubed to the bottom side of the actuator. The Output 2 port of the positioner manifold is tubed to the top side of the actuator. This tubing convention is followed regardless of air action. On rotary actuators, the transfer case orientation determines the air action.

### Single-acting Actuators

For single-acting actuators, the Output 1 port is always tubed to the pneumatic side of the actuator regardless of air action. The Output 2 port must be plugged.

## 6 Wiring and Grounding Guidelines (See Figure 6)

 **WARNING:** This product has electrical conduit connections in either thread sizes  $\frac{1}{2}$ " NPT or M20 which appear identical but are not interchangeable. Housings with M20 threads are stamped with the letters M20 above the conduit opening. Forcing dissimilar threads together will damage equipment, cause personal injury and void hazardous location certifications. Conduit fittings must match equipment housing threads before installation. If threads do not match, obtain suitable adapters or contact a Flowserve representative.

### 6.1 FF Command Input Wiring

The Logix 3400IQ is non-polarity sensitive. Wire FF source to the input terminals (see Figure 6). Minimum operating voltage is 9 VDC.


The FF signal to the Logix 3400IQ digital positioner should be in shielded cable. Shields must be tied to a ground at only one end of the cable to provide a place for environmental electrical noise to be removed from the cable. In general, shield wire should be connected at the source. Refer to guidelines in FF AG-181 for proper wiring methods.

**NOTE:** The Logix 3400IQ positioner carries an intrinsically safe barrier rating of 250 mA. Input currents should not exceed 250 mA, 5 watts.

### 6.2 Grounding Screw

The green grounding screw, located inside the termination cap, should be used to provide the unit with an adequate and reliable earth ground reference. This ground should be tied to the same ground as the electrical conduit. Additionally, the electrical conduit should be earth grounded at both ends of its run.

Figure 6: Field Termination



**WARNING:** The green grounding screw must not be used to terminate signal shield wires.

### 6.3 Segment Compliance Voltage (See Figure 7)

Output compliance voltage refers to the voltage limit that can be provided by the FF source. A FF system consists of the FF source, wiring resistance, barrier resistance (if present), and the Logix 3400IQ positioner voltage. The Logix 3400IQ digital positioner requires that the system allows for a 9.0 VDC drop across the positioner at minimum segment voltage. The actual voltage at the terminals varies from 9.0 to 32.0 VDC depending on the FF signal and ambient temperature.

Determine if the segment will support the Logix 3400IQ digital positioner by performing the following calculation.

20

$$\text{Voltage} = \text{Compliance Voltage (@ 23 mA)} - 23 \text{ mA} \cdot (R_{\text{barrier}} + R_{\text{wire}})$$

Equation 1

The calculated voltage must be greater than 9 VDC in order to safely support the Logix 3400IQ digital positioner.

Example:

DCS Compliance Voltage = 19 VDC

$R_{\text{barrier}} = 300 \Omega$


$R_{\text{wire}} = 25 \Omega$

Current<sub>max</sub> = 23 mA

Voltage = 19 VDC – 0.023 A • (300  $\Omega$  + 25  $\Omega$ ) = 11.5 VDC

The voltage 11.5 VDC is greater than the required 9.0 VDC; therefore, this system will support the Logix 3400IQ digital positioner.

Figure 7: Compliance Voltage



## 6.4 Cable Requirements

The Logix 3400IQ digital positioner utilizes the FF protocol. This communication signal is superimposed on the supply voltage.

FF rated cable should be used. Refer to H1 wiring specification.

## 6.5 Intrinsically Safe Barriers


When selecting an intrinsically safe barrier, make sure the barrier is FF compatible. Although the barrier will pass the segment voltage and allow normal positioner operation, if not compatible, it may prevent FF communication.

## 6.6 DD Support

The DD for the Logix 3400IQ can be downloaded from either the flowserve website: [www.flowserve.com](http://www.flowserve.com) or the FOUNDATION Fieldbus website: [www.Fieldbus.org](http://www.Fieldbus.org).

## 7 Startup

Figure 8: Local User Interface



### 7.1 Logix 3400IQ Local Interface Operation

The Logix 3400IQ local user interface (Figure 8) allows the user to configure the basic operation of the positioner, tune the response, and calibrate the positioner without additional tools or configurators. The local interface consists of a RE-CAL button for automatic zero and span setting, along with two jog buttons (▲ and ▼) for spanning valve/actuators with no fixed internal stop in the open position. There is also a DIP switch block containing eight switches. Six of the switches are for basic configuration settings and two are for FF options. There is also a rotary selector switch for adjusting the positioner gain settings. For indication of the operational status or alarm conditions there are three LEDs on the local user interface.

### 7.2 Initial DIP Switch Settings

Before placing the unit in service, set the DIP switches in the Configuration boxes to the desired control options. A detailed description of each DIP switch setting follows.

**NOTE:** The Logix 3400IQ positioner reads the DIP switch settings each time the RE-CAL button is pressed. If a FF handheld or Host software is used to configure and then calibrate the positioner, the DIP switches are not read. The auto-tune adjustment switch labeled “GAIN” is always live and can be adjusted at any time.

**22** Transducer block settings will always override the DIP switch settings until the RE-CAL button is pressed.

## 7.3 Description of Configuration DIP Switch Settings

The first six DIP switches are for basic configuration. The function of each switch is described below.

### **Air Action**

This must be set to match the configuration of the valve/actuator mechanical tubing connection and spring location since these determine the air action of the system.

### **ATO (air-to-open)**

Selecting ATO if increasing output pressure from the positioner is tubed so it will cause the valve to open.

### **ATC (air-to-close)**

Selecting ATC if increasing output pressure from the positioner is tubed so it will cause the valve to close.

### **Pos. Characterization**

**Linear** Select *Linear* if the actuator position should be directly proportional to the input signal.

**Other** Select *Other* if another characteristic is desired, which is set in conjunction with the **Control\_Flags** parameter in the transducer block.

### **Optional Pos. Characterization**

If the Pos. Characterization switch is set to Other then this parameter is active with the following options:

**=%** The =% option will characterize the actuator response to the input signal based on a standard 30:1 equal percent rangeability curve.

**Q0** Quick open is based on a standard industry quick-open curve.

**Custom** If *Custom* is selected, the positioner will be characterized to a custom table that must be set-up using a properly configured 375 handheld or other host software. *Custom* characterization can be thought of as a “soft CAM.” The user can define a characterization curve using 21 points. The control will linearly interpolate between points. Points do not have to be equally spaced in order to allow more definition at critical curve areas. The default values will linearize the output of a valve with an inherent =% characteristic (e.g. ball valves.)

Figure 9: Default Custom Characterization




Table VI : Characteristic Curve Data

% Command	% Control Command			
	=%	Linear	Custom	QO
0	0	0	0	0
5	0.62	5	8.66	18.8
10	1.35	10	16.24	37.6
15	2.22	15	23.17	56.4
20	3.25	20	30.11	74.0
25	4.47	25	35.31	84.3
30	5.91	30	40.51	90.0
35	7.63	35	45.42	92.0
40	9.66	40	50.34	93.4
45	12.07	45	54.40	94.2
50	14.92	50	58.47	94.8
55	18.31	55	62.39	95.5
60	22.32	60	66.31	96.0
65	27.08	65	70.27	96.5
70	32.71	70	74.23	97.0
75	39.40	75	78.17	97.5
80	47.32	80	82.11	98.0
85	56.71	85	85.50	98.5
90	67.84	90	88.89	99.0
95	81.03	95	94.45	99.5
100	100.00	100	100.00	100.0



### Auto Tune

This switch controls whether the positioner will auto tune itself every time the RE-CAL button is pressed or use preset tuning parameters.

**On** *On* enables an auto tune feature that will automatically determine the positioner gain settings based on the current position of the adjustable GAIN switch setting and response parameters measured during the last RE-CAL. The GAIN switch is live, meaning the settings can be adjusted at any time by changing the rotary switch position. (Note that there is a small black arrow indicating the selection. The slot in the switch is NOT the indicator.)

Figure 10: Adjustable GAIN Switch



If the adjustable GAIN selector switch is set to “E” with the auto tune switch on, a Flowserve standard response tuning set will be calculated and used based on response parameters measured during the last RE-CAL.

If the adjustable GAIN selector switch is set to “D”, “C”, “B”, or “A” with the auto tune switch on, progressively lower gain settings will be used based on response parameters measured during the last RE-CAL.

If the adjustable GAIN selector switch is set to “F”, “G”, or “H” with the auto tune switch on, progressively higher gain settings will be calculated and used based on response parameters measured during the last RE-CAL.

**Off** *Off* forces the positioner to use one of the factory preset tuning sets determined by the adjustable GAIN selector switch. Settings “A” through “H” are progressively higher gain predefined tuning sets. The GAIN selector switch is live and can be adjusted at any time to modify the tuning parameters.

**NOTE:** “E” is the default adjustable GAIN selector switch setting for all actuator sizes. Raising or lowering the gain setting is a function of the positioner/valve response to the control signal, and is not actuator size dependent.

### Stability Switch

This switch adjusts the position control algorithm of the positioner for use with low-friction control valves or high-friction automated valves.

**Low-Friction Valves** Placing the switch to the left optimizes the response for low-friction, high-performance control valves. This setting provides for optimum response times when used with most low-friction control valves.

**High-Friction Valves** Placing the switch to the right optimizes the response for valves and actuators with high friction levels. This setting slightly slows the response and will normally stop limit cycling that can occur on high-friction valves.


## 7.4 Description of Cal DIP Switch Settings

The sixth DIP switch selects between two calibration options. The function of the Cal DIP switch is described below.

**NOTE:** The unit must be in OOS mode before a calibration sequence can begin.

**Auto** Select *Auto* if the valve/actuator assembly has an internal stop in the open position. In *Auto* mode the positioner will fully *close* the valve and register the 0% position and then *open* the valve to the stop to register the 100% position when performing a self-calibration. See detailed instructions in the next section on how to perform an auto positioner calibration.

**Jog** Select *Jog* if the valve/actuator assembly has no physical calibration stop in the open position. In the *Jog* mode the positioner will fully close the valve for the 0% position and then wait for the user to set the open position using the Jog buttons labeled with the up and down arrows. See the detailed instructions in Section 7.6 on how to perform a manual calibration using the Jog buttons.

 **WARNING:** During the RE-CAL operation the valve may stroke unexpectedly. Notify proper personnel that the valve will stroke, and make sure the valve is properly isolated.

## 7.5 RE-CAL Operation

**NOTE:** The unit must be in OOS mode before a calibration sequence can begin.

The RE-CAL button is used to locally initiate a calibration of the positioner. Pressing and holding the RE-CAL button for approximately three seconds will initiate the calibration. If the Config-Switches option is enabled, the settings of all the configuration switches are read and the operation of the positioner adjusted accordingly. A RE-CAL can be aborted at any time by briefly pressing the RE-CAL button and the previous settings will be retained.

If the Quick Calibration switch (be careful not to confuse this with the RE-CAL button) is set to Auto and the valve/actuator assembly has the necessary internal stops the calibration will complete automatically. While the calibration is in progress you will notice a series of different lights flashing indicating the calibration progress. When the lights return to a sequence that starts with a green light the calibration is complete. An explanation of the various light sequences follows. The initial calibration of extremely large or small actuators may require several calibration attempts. The positioner adapts to the actuator performance and begins each calibration where the last attempt ended. On an initial installation it is recommended that after the first successful calibration that one more calibration be completed for optimum performance.

- ⚠ WARNING:** When operating using RE-CAL or local control, the valve will not respond to external commands. Notify proper personnel that the valve will not respond to remote command changes, and make sure the valve is properly isolated.

## 7.6 Manual Jog Calibration Operation

If the Quick Calibration switch is set to Jog, the calibration will initially close the valve then cause a small jump in the valve position. The jog calibration process will only allow the user to manually set the span; zero position is automatically always set at the seat. If an elevated zero is needed a handheld or other PC-based configuration software is required. When performing a jog calibration, the LEDs will flash in a sequence of Y-R-R-G (yellow-red-red-green) which indicates that the user must use the Jog buttons (▲ and ▼) to manually position the valve to the 100% position. When the stem is properly positioned press both the Jog buttons (▲ and ▼) simultaneously again to register the 100% position and proceed. No more user actions are required while the calibration process is completed. When the lights return to a sequence that starts with a green light the calibration is complete. An explanation of the various light sequences follows.

## 7.7 Local Control of Valve Position

Local control of valve position can be achieved from the user interface by holding down both Jog buttons and the RE-CAL button simultaneously for three seconds. While in this mode the LEDs will flash a YGRR (yellow-green-red-red) sequence. Use the two Jog buttons (▲ and ▼) to manually control the position of the valve. To exit the local control mode and return to normal operation, briefly press the RE-CAL button.

## 7.8 Factory Reset

To perform a factory reset, disconnect power, hold the RE-CAL button down, and reconnect power. Performing a factory reset will cause all of the internal variables, including calibration, to be reset to factory defaults. The positioner must be recalibrated after a factory reset. User configured limits, alarm settings, and valve information will also need to be restored.

- ⚠ WARNING:** Performing a factory reset may result in the inability to operate the valve until reconfigured properly. Notify proper personnel that the valve may stroke, and make sure the valve is properly isolated.

## 7.9 Logix 3400IQ Status Condition

The blink codes used to convey the status of the Logix 3400IQ digital positioner are described in the table below. In general, any sequence starting with a green light flashing first is a normal operating mode and indicates that there are no internal problems. Any sequence starting with a yellow light flashing indicates that the unit is in a special calibration or test mode, or that there was a calibra-

tion problem. Any sequence starting with a red light flashing indicates that there is an operational problem with the unit.

Table VII: Status and Conditions

Colors	Identifier	Indication and Resolution
G - - -		<b>Any sequence starting with a green light flashing first is a normal operating mode and indicates that there are no internal problems.</b>
GGGG	1	<b>Normal operation</b> No errors, alerts, or warnings.
GGGY	2	<b>Final Value cutoff active</b> The command is below or above the user-set limits for tight shutoff feature. This is a normal condition for a closed valve. The factory default setting is 1% and 110% command. To clear the condition use handheld or Host software to reset the tight shutoff if the range is incorrect or adjust the command signal above the specified Final Value cutoff.
GGYR	4	<b>Initializing</b> This sequence should only be visible for three sequences when powering up the unit.
GGRG	5	<b>Cycle limit exceeded (user-set)</b> The cycle limit set by the user has been exceeded. To clear use handheld or Host software to reset.
GGRY	6	<b>Travel limit exceeded (user-set)</b> The total accumulated travel limit set by the user has been exceeded. To clear use handheld or Host software to reset.
GYR	7	<b>Soft Stop Low (user-set)</b> The unit is being commanded to exceed a user-defined lower position limit and the internal software is holding the position at the limit. The function is similar to a mechanical limit stop except it is not active if the unit is un-powered. To clear the condition use handheld or Host software to reset the limit if more travel is needed or adjust the command signal back in the specified range.
GYRY	8	<b>Soft Stop High (user-set)</b> The unit is being commanded to exceed a user-defined upper position limit and the internal software is holding the position at the limit. The function is similar to a mechanical limit stop except it is not active if the unit is un-powered. To clear the condition use handheld or Host software to reset the limit if more travel is needed or adjust the command signal back in the specified range.
GRYR	9	<b>Posalert Low (user-set)</b> The position has reached or is exceeding a user-defined lower position indicator similar to a limit switch indicator. To clear the condition use handheld or Host software to reset the indicator if more travel is needed or adjust the command signal back in the specified range.
GRRY	10	<b>Posalert High (user-set)</b> The position has reached or is exceeding a user-defined upper position indicator similar to a limit switch indicator. To clear the condition use handheld or Host software to reset the indicator if more travel is needed or adjust the command signal back in the specified range.
Y - - -		<b>Any sequence starting with a yellow light indicates that the unit is in a special calibration or test mode, or that there was a calibration problem.</b>
YGYG	11	<b>Signature test in progress</b> This is a test initiated by Host software that can only be cancelled by that software.
YRGG	13	<b>Stroke calibration in progress</b> Calibration sequence started either using the local RE-CAL button or by a handheld or Host software. It may be cancelled by briefly pushing the RE-CAL button.

Table VII: Status and Conditions (continued)

Colors	Identifier	Indication and Resolution
YGRR	14	<b>Local jog control mode</b> The unit has been placed in a local override mode where the valve can only be stroked using the two local jog buttons. It may be cancelled by briefly pushing the RE-CAL button.
YYGR	15	<b>Pressure calibration in progress</b> Calibration sequence controlled by a handheld or Host software that can only be cancelled by that software.
YYYY	16	<b>Local user interface disabled</b> Host software has been used to disable the local interface. If local control is desired then the local interface must be re-enabled from the remote software. This code is only present for a short time when the RE-CAL button is pressed.
YRRG	17	<b>Waiting</b> Adjust to full open position setting from User—only used during Jog calibration see explanation in Section 7.5, “RE-CAL,” for operation.
YRYG	18	<b>Setting IL offset while calibrating</b> An automatic step in the calibration process that is done with the valve at 50% position. This must be completed for proper calibration.
YRY Y	19	<b>No feedback motion while calibrating</b> Indicates that there was no motion of the actuator based on the current stroke time configuration. Check linkages and air supply to make sure the system is properly connected. If the time out occurred because the actuator is very large then simply retry the RE-CAL and the positioner will automatically adjust for a larger actuator by doubling the time allowed for movement. This error may be cleared by briefly pushing the RE-CAL button, which will force the positioner to use the parameters from the last good calibration.
YRYR	20	<b>Feedback 0% out of range</b> Calibration error indicating that the position sensor was out of range during the calibration of the closed position. To correct the condition, adjust the positioner mounting, linkage or feedback potentiometer to move the position sensor back into range then restart the calibration. This error may be cleared by briefly pushing the RE-CAL button, which will force the positioner to use the parameters from the last good calibration.
YRRY	21	<b>Feedback 100% out of range</b> Calibration error indicating that the position sensor was out of range during the calibration of the open position. To correct the condition, adjust the positioner mounting, linkage or feedback potentiometer to move the position sensor back into range then restart the calibration. This error may be cleared by briefly pushing the RE-CAL button, which will force the positioner to use the parameters from the last good calibration.
YRRR	22	<b>Feedback span too small</b> The range of motion of the position feedback arm was too small for optimum performance. Check for loose linkages and/or adjust the feedback pin to a position closer to the follower arm pivot to create a larger angle of rotation and recalibrate. Briefly pushing the RE-CAL button acknowledges this condition and the positioner will operate using the current short stroke calibration if otherwise a good calibration.
YRGR	23	<b>Feedback unstable while calibrating</b> Check for loose linkages or loose positioner sensor. This error may be cleared by briefly pushing the RE-CAL button, which will force the positioner to use the parameters from the last good calibration. This error may appear on some very small actuators during the initial calibration. Redoing the calibration may clear the problem.
R - - -		<b>Any sequence starting with a red light indicates that there is an operational problem with the unit.</b>
RGRR	24	<b>Position deviation (user-set)</b> The position has exceeded user-defined error band between command and position.
RGYY	25	<b>Pressure reading out of range</b> The internal pressure sensors are either saturated with a pressure over 150 psi or the sensor has failed. Check supply pressure and if OK check the pressure sensor board connections and replace pressure sensor board if necessary.

Continued on page 30

Table VII: Status and Conditions (continued)

Colors	Identifier	Indication and Resolution
RGYR	26	<b>Loss of supply pressure</b> The Positioner has determined that the supply pressure is below 15 psi. Check the supply pressure and if OK check the pressure sensor board connections and replace pressure sensor board if necessary. Minimum recommended supply pressure is 30 psi for proper operation.
RYGG		<b>Factory reset condition</b> Recalibrate.
RYYY	27	<b>Pilot relay non-motion alert</b> Check to make sure the air supply is connected. Also check the internal wiring harnesses for good connections. This error may be cleared by briefly pushing the RE-CAL button, which will force the positioner to use the parameters from the last good calibration. If the positioner still does not operate replace the pneumatic relay assembly.
RRGG	30	<b>Watchdog timer timeout (also listed as internal voltage reference)</b> This is often caused when intermittent operation occurs when connecting power. Remove power and then reconnect to clear. If problem persists it is a bad electronic assembly, replace.
RRYG	31	<b>Internal temperature alert</b> The internal positioner temperature is currently exceeding operational limits of -40°F (-40°C) or 185°F (85°C).
RYYY	32	<b>Piezo voltage error</b> Bad electronic assembly, replace.
RRYR	33	<b>Internal voltage reference error</b> Indicates that the circuit board is drawing too much power. Check internal wiring and connectors for electrical shorts—if no shorts are present, replace the electronic assembly.
RRRG		<b>Loss of Inter-PCB Communications</b> Cycle power to restart.
RRRY	34	<b>NV RAM checksum error</b> The checksum of the internal data was not updated correctly. Cycle power and complete a RE-CAL if error persists. Check internal data to verify correct settings. If the error still occurs, replace the electronic assembly.

## 7.10 Version Number Checking

The version number of the embedded code may be checked at any time except during a calibration by holding down the up arrow Jog button (▲). This will not alter the operation of the unit other than to change the blink sequence to three blinks indicating the major version number. Holding the down arrow Jog button (▼) will give the minor version number without affecting operation. The version codes are interpreted by adding up the numbers assigned according to the following table:

Color	First blink value	Second blink value	Third blink value
Green	0	0	0
Yellow	9	3	1
Red	18	6	2

For example if holding the up arrow Jog button (▲) gave a G-G-R code, and holding the down arrow Jog button (▼) gave a Y-Y-G code then the resulting version number would be (0+0+2).(9+3+0) or version 2.12.

## 7.11 375 Handheld Communicator

The Logix 3400IQ Quick Start Guide is available from a Flowserve representative.

The Logix 3400IQ digital positioner supports and is supported by the 375 Handheld Communicator. The Device Description (DD) files and the manuals listed below can be obtained from the FF Foundation or from your Flowserve representative. For more information please see the following guides:

- Product Manual for the 375 Communicator.
- Logix 3400IQ Digital Positioner Reference Manual.

Diagnostic features such as the signature tests and ramp tests are performed internally. Certain calibration features such as actuator pressure sensor calibrations are performed using the 375 Handheld Communicator or using the Host software.

## 7.12 Device Description (DD) Files

The DD files for the Logix 3400 can be downloaded from the Flowserve website, <http://fcd.flowserve.com/valves/softwareDownload.jsp>, or the Foundation Fieldbus website, [www.fieldbus.org](http://www.fieldbus.org).

## 7.13 Calibration

### 7.13.1 CALIBRATE\_FLAGS

#### **Position 0% Calibration Flag in CALIBRATE\_FLAGS**

During stroke calibration, the Logix 3400 digital positioner checks to see if the linkage is placing the stem position sensor in range. If the valve stroke causes stem position measurement to go out of range in the closed position, a Position 0% Flag will be generated. The valve stem will stop in the closed position and the red LED will blink. Linkage must be adjusted to bring the sensor in range. Special LED indication: If the linkage is out of range, the LEDs can be used as an adjustment guide. The LED will change from a red to yellow when the linkage is brought into range.

#### **Position 100% Calibration Flag in CALIBRATE\_FLAGS**

During stroke calibration, the Logix 3400IQ digital positioner checks to see if the linkage is placing the stem position sensor in range. If the valve stroke causes stem position measurement to go out of range in the open position, a Position 100% Flag will be generated. The valve stem will stop in the open position and the red LED will blink. Linkage must be adjusted to bring the sensor in range. Special LED indication: If the linkage is out of range, the LEDs can be used as an adjustment guide. The LED will change from a red to yellow when the linkage is brought into range.

### Position Span Flag in CALIBRATE\_FLAGS

Position span is a check during stroke calibration to verify that the valve stem moved. The algorithm waits to see if no movement is detected when the valve is automatically stroked open. Anything that could prevent the valve from stroking will generate a Position Span error (no supply pressure, malfunctioning spool valve).

## 7.13.2 Control and Tuning

### Setting P + I Parameters

Using the Host configurator, you can set individual tuning parameters. A few key points are mentioned below. (See Figure 11.)

**GAIN\_UPPER, GAIN\_LOWER, and GAIN\_MULT:** These three parameters are related by the following formula.

Proportional Gain =

Maximum Gain - | deviation | x Gain Multiplier

If Proportional Gain < Minimum Gain, then Proportional Gain = Minimum Gain

This algorithm allows for quicker response to smaller steps yet stable control for large steps. Setting the gain multiplier to zero and max gain = min gain results in a typical fixed proportional gain.

The higher the gain multiplier, the larger the required deviation before the gain increases. Default values upon initiating a RESET to factory defaults (under LOAD\_EE\_DEFAULTS) are maximum gain = 2.0, minimum gain= 1.0, and gain multiplier= 0.05. These values will allow stable control on all Valtek control product actuator sizes.

**Integral Gain (IGAIN):** The integral gain is primarily for deviations due to temperature drift within the inner loop spool control. The factory default value is 10. Although higher numbers can speed the time it takes to reach zero deviation, it can add overshoot if too large. It is recommended that maximum and minimum gains be adjusted while leaving integral gain fixed at 10. Integration is disabled below a stem position of 3 percent and above a stem position of 97 percent. This is to prevent integration windup from calibration shifts due to lower pressure or a damaged seat that may prevent fully closing the valve.

**Integration Summer:** The integral summer within the Logix 3400IQ digital positioner is clamped at +20 percent and -20 percent. If the integration summer is fixed at +20 percent or -20 percent, it usually indicates a control problem. Some reasons for a clamped integration summer are listed below:

- Stroke calibration incorrect.
- Any failure which prevents stem position movement: stuck spool, handwheel override, low pressure.
- Incorrect inner loop offset.
- Loss of air supply on a fail in place actuator.



Writing a zero to integral gain (IGAIN) will clear the integral summer. The integral gain can then be returned to its original value.

**Inner loop offset (IL\_OFFSET):** Three control numbers are summed to drive the inner loop spool position control: proportional gain, integral summer, and inner-loop offset.

Inner-loop offset is the parameter that holds the spool in the ‘null’ or ‘balance’ position with a control deviation of zero. This value is written by the positioner during stroke calibration and is a function of the mechanical and electrical spool sensing tolerances. However, if it becomes necessary to replace the driver module assembly or the software RESET calibration constants has been performed, it may be necessary to adjust this value. The method below should be used to adjust inner-loop offset.

Or simply perform a new stroke calibration.

From the fieldbus configurator:


- Set transducer block to OOS
- Enable Diagnostic Variable access in TEST\_MODE
- Send a 50 percent command.
- Set integral to zero.
- Locate the DAC\_PERCENT
- Write this percentage value to IL\_OFFSET
- Write original value to Integral

These tuning sets can be used to obtain initial values for Flowserve products and comparable actuator sizes. The user may need to adjust this tuning to achieve optimal performance for a particular application.

Table VIII: Factory Tuning Sets

Mfg.	Tuning Set	GAIN_LOWER	GAIN_UPPER	GAIN_MULT	Igain	Comparable Size (in <sup>2</sup> )
Valtek	VFactory_A	1.0	2.0	0.05	10	25
	VFactory_B	1.0	2.5	0.05	10	50
	VFactory_C	2.0	3.0	0.05	10	100
	VFactory_D	4.0	5.0	0.05	10	200
	VFactory_E	4.0	7.0	0.05	10	300
	Trooper 48	0.4	0.5	0.05	25	31
Kammer	Trooper 49	3.0	4.0	0.05	10	77.5
	Trooper 48	0.4	0.5	0.05	25	31
	Trooper 49	3.0	4.0	0.05	10	77.5
Automax	R1	0.3	0.5	0.05	10	3 to 5
	R2	1.0	1.5	0.05	10	9 to 12
	R3	1.3	2.0	0.05	10	16 to 19
	R4	2.0	2.5	0.05	10	27 to 37
	R5	2.5	3.6	0.05	10	48 to 75
	R6	4.0	5.0	0.05	10	109

Figure 11: Logix 3400 Block Diagram



## 7.14 Alerts

### 7.14.1 FINAL\_VALUE\_CUTOFF

The FINAL\_VALUE\_CUTOFF or tight shutoff feature of the Logix 3400IQ digital positioner allows the user to control the level at which the command signal causes full actuator saturation in the closed or open position.

This feature can be used to guarantee actuator saturation in the closed or open position or prevent throttling around the set at small command signal levels. To enable, use configuration to apply the desired FINAL\_VALUE\_CUTOFF threshold.

**NOTE:** The positioner automatically adds a 1 percent hysteresis value to the FINAL\_VALUE\_CUTOFF\_LO setting to prevent jumping in and out of saturation when the command is close to the setting.

### 7.14.2 Effects of FINAL\_VALUE\_CUTOFF on Operation

With the FINAL\_VALUE\_CUTOFF\_LO set at 5 percent the positioner will operate as follows: Assume that the present command signal is at 50 percent. If the command signal is decreased, the positioner will follow the command until it reaches 5 percent.

At 5 percent, full actuator saturation will occur. The actuator will maintain full saturation below 5 percent command signal. Now, as the command increases, the positioner will remain saturated until the command reaches 6 percent (remember the 1 percent hysteresis value added by the positioner). At this point, the stem position will follow the command signal.

If the FINAL\_VALUE\_CUTOFF\_LO is set to 3 percent but the valve will not go below 10 percent, SOFTSTOP\_LOW may be enabled. The lower soft limit must be less than or equal to 0 percent in order for the FINAL\_VALUE\_CUTOFF\_LO to become active.

If soft stops are active (ie: SOFTSTOP\_LOW = 0 or SOFTSTOP\_HIGH = 100) FINAL\_VALUE\_CUTOFF is disabled.

### 7.14.3 Soft Limits

Unlike position alerts, soft limits prevent the stem position from going below or above the configured limits. If the command signal is trying to drive the position past one of the limits, the yellow LED will blink but the stem position will remain at the set limit.

### 7.14.4 Travel Accumulator

The travel accumulator is equivalent to a car odometer and sums the total valve movement. Using the user defined stroke length and travel dead-band, the Logix 3400IQ digital positioner keeps a running total of valve movement. When the positioner first powers up, high and low dead-band limits are calculated around the present position. When the stem position exceeds the travel dead-band, the movement from the center of the deadband region to the new position is calculated and added to the travel accumulator. From this new position, deadband high and low limits are again calculated.

**EXAMPLE:** The Logix 3400IQ digital positioner has a default dead-band configuration of 20 percent. The valve has a 4 inch linear stroke. When the valve first powers up, the command signal is 50 percent. The unit will calculate a high travel threshold of 70 percent (50 percent present position plus 20 percent dead-band) and a low travel threshold of 30 percent (50 percent present position minus 20 percent dead-band). As long as the stem position remains greater than 30 percent and less than 70 percent, no additions are made to the travel accumulator. Now, assume the stem position moves to 80 percent that is outside the present dead-band. The Logix 3400IQ digital positioner calculates the stem movement and adds this number to the travel accumulator.

80 percent (present position) - 50 percent (previous) =  
30 percent movement x 4-inch stroke = 1.2 inches

So, 1.2 inches is added to the travel accumulator. New dead-band thresholds of 100 percent (80 percent present position plus 20 percent dead-band) and 60 percent (80 percent present position minus 20 percent dead-band) are calculated. This process continues as the stem position moves throughout its stroke range.

#### 7.14.5 Cycle Counter

The cycle counter is another means of monitoring valve travel. Unlike the travel accumulator, the stem position must do two things to count as a cycle: exceed the cycle counter dead-band and change direction. A cycle counter limit can also be written into the positioner. If this limit is exceeded, the yellow LED will blink.

#### 7.14.6 Position Deviation

If the stem position differs from the control command by a certain amount for a given length of time, the yellow LED will blink to signify excess deviation. The trip point and settling times are set from the transducer function block.

#### 7.14.7 Advanced Features

**NOTE:** These features are contained in the transducer function block. Refer to the Reference Manual for a more detailed explanation.

#### 7.14.8 Standard vs. Advanced Diagnostics

Advanced diagnostics models add top, bottom, and supply pressure sensors. This allows for more diagnostic calculations such as loss of pressure, advanced signatures, and troubleshooting.

#### 7.14.9 Temperature and Pressure Units

The desired temperature and pressure units can be set during configuration. Once set, all readings will be displayed in the desired units.

### 7.14.10 Stroke Length

Stroke length is used by the travel accumulator. When the stroke length and units are set, the length is used to determine the total travel accumulated. The travel accumulator will have the units associated with stroke.

**EXAMPLE:** Stroke length is set to four inches. If the valve is moved from 0 percent to 100 percent, four inches will be added to the travel accumulator. The travel accumulator units will be inches. If Stroke length is 90 degrees for a rotary, the travel accumulator will now have units of degree. A 0 percent to 100 percent stroke will add 90 to the travel accumulator.

**NOTE:** Stroke length is for information only and is not used during calibration.

Table IX: Transducer Block Characterization Parameters

Parameter	Description	Value - Meaning	Comments
MODE_BLK	The operating mode of the transducer block	Auto - Auto (target mode)	The transducer block must be out of service before characterization can be edited or changed
		OOS - Out of Service	
CONTROL_FLAGS	Byte values which select positioner operation features	1 - Quick Opening Curve*	Loads factory-defined QO curve as custom curve.
		2 - Equal Percent Curve*	Loads factory-defined equal percent curve as custom curve.
		3 - Actuator Type	
		4 - Advanced Model	
		5 - Rotary Actuator Gain	
		6 - Custom Characterization Active	Activates custom curve. If Off, response is Linear.
		7 - Fail Position TBD	
		8 - Air Action	
CURVEX	Numeric X value array for custom point. (1 x 21 array points)	X-axis value for custom stroke characterization point. Range -10 to 110	Pair each X-value with corresponding Y-value to define the desired point. Values must be in ascending (or equal) order.
CURVEY	Numeric Y value array for custom point. (1 x 21 array points)	Y-axis value for custom stroke characterization point. Range -10 to 110	

\*NOTE: Must not be selected if a custom curve is to be created or edited.

## 7.15 Characterization Retention


Once a custom curve has been loaded into the Logix 3400IQ digital positioner's memory it is retained in the EPROM until it is either edited or replaced. Turning Custom Characterization Active on or off now selects between a linear response (off), or the new custom curve (on). If either of the other two factory curves is selected it will overwrite the custom curve in RAM only. The custom user-defined curve will automatically be activated again when the factory curve is deselected.

### 7.15.1 Initiating a Valve Signature

A feature of the Logix 3400 positioner is the ability to capture and store a valve diagnostic signature. A signature is the collected data response of the valve to a predefined set of operating conditions. This stored data can later be uploaded to the host system for analysis of potential problems. By comparing a baseline signature, when the valve is new, to subsequent signatures at later times, a rate of change can be tracked which can help predict possible faults in the valve before they happen. This is called 'predictive maintenance'. It is important to note that the purpose of the positioner is to act as the data acquisition device for the signature. Analysis of the data is not done on the device, but in the supervisory system.

**NOTE:** Signature data is lost if the positioner is reset or if the power is cycled

### 7.15.2 System Preparation

 **WARNING:** By definition, the collection of the signature requires the unmanaged operation of the positioner. Therefore, the process must be in a safe operating mode where unexpected movement of the valve will not cause a hazardous condition.

Before a valve signature can be run, the Transducer Block must Out-of-Service (OOS).

### 7.15.3 Signature Procedure

The following steps are an example of how to initiate a ramp signature capture.

1. Make sure the process is in safe condition and notify the control room that the valve will temporarily be taken off-line.
2. Verify preparedness to proceed.
3. Put the Transducer block `MODE_BLK OOS`
4. Set `SIG_START` to desired value.
5. Set `SIG_STOP` to desired value.
6. Set `SAMPLE_TIME` to desired value (typically 0.3).
7. In `SIG_FLAGS`, select; `STEP_RAMP`, `PRESS_MEAS`.
8. Write values to the Logix 3400IQ digital positioner.

9. Set RAMP\_RATE to desired value (typically 100).
10. Write value to the Logix 3400IQ digital positioner.
11. In SIG\_FLAGS, select BEGIN\_SIG.
12. Write value to the Logix 3400IQ digital positioner.
13. The valve will stroke to the beginning position, as defined by SIG\_START and will begin ramping to the desired ending position, as defined by SIG\_STOP.

Notice that SIG\_COUNTER will increment while this takes place. (Typically approximately 670 data sets will be collected with the above settings and full stroke of the valve. Exact numbers will vary.)

14. SIG\_FLAGS indicates SIG COMPLETE.
15. Return the MODE\_BLK to auto.
16. Notify control room the valve is back on-line. The stored signature will remain in the Logix 3400IQ digital positioner RAM until the either the unit is powered down, or another signature is taken which overwrites the previous one.

## 7.16 Step Signature

If a step signature was desired, simply do not select STEP\_RAMP in SIG\_FLAGS, and then set the STEP\_TIME prior to selecting BEGIN\_SIG.

### 7.16.1 Collection of Stored Signature

The collection of the stored signature is accomplished by the host system. It is not part of the device. See host system programming. A simple utility using National Instruments NI-FBUS is available from Flowserve for retrieving a signature file.

The retrieved file is stored in a text format that can be imported into other programs for plotting and analysis. Contact Flowserve for more details.

## 7.17 Glossary

**A/D** Also called ADC. Analog-to-digital converter. An A/D converts an analog signal into an integer count. This integer count is then used by the microcontroller to process sensor information such as position, pressure, and temperature.

**D/A** Also called DAC. Digital-to-analog converter. A D/A converts an integer count into an analog output signal. The D/A is used to take a number from the microcontroller and command an external device such as a pressure modulator.

**EEPROM (Electrically Erasable Programmable Read Only Memory)** A device that retains data even when power is lost. Electrically erasable means that data can be changed. EEPROM have a limited number of times data can be rewritten (typically 100,000 to 1,000,000 writes).

**Micro-controller** In addition to an integral CPU (microprocessor), the micro-controller has built in memory and I/O functions such as A/D and D/A.

**Microprocessor** Semiconductor device capable of performing calculations, data transfer, and logic decisions. Also referred to as CPU (Central Processing Unit).

**Protocol** A set of rules governing how communications messages are sent and received.

**Resolution** Resolution is a number which indicates the smallest measurement which can be made. You will often see analog-to-digital (A/D) converters referred to as a 10-bit A/D or a 12-bit A/D. 10-bit and 12-bit are terms which indicate the total number of integer counts which can be used to measure a sensor or other input. To determine the total integer count, raise 2 to the power of the number of bits.

Example: 12-bit A/D

Total integer number = 2

Number of Bits =  $2^{12}$  = 4096

Resolution is the measurement range divided by the maximum integer number.

Example: A valve has a 2-inch stroke and a 12-bit A/D is used to measure position.

Resolution = Stroke/(Maximum Integer for 12-bit) = 2 inch/4096 = 0.000488 inches

**Sampling** Taking readings at periodic time intervals.

**Serial Channel** Channel that carries serial transmission. Serial transmission is a method of sending information from one device to another. One bit is sent after another in a single stream.



## 7.18 Transducer Block Parameters

Table X: Transducer Block Parameters

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt Rd					
<b>CONTROL</b>								
1	AD_RAW_FB	signed int	No	Integer 16	R	0	4095	12-bit A/D Feedback counts
2	FINAL_VALUE	signed int	/100	DS-65	R/W*	-10%	110%	Digital Command signal in %
3	FINAL_POSITION_VALUE	signed int	/100	DS-65	R			Actual Feedback position in %
4	ERROR	signed int	/100	float	R			Position deviation in %
5	DAC_PERCENT	signed int	/100	float	R	0%	100%	12-bit DAC output in %
6	CONTROL_FLAGS	unsigned char	No	Bit String	R/W*			Valve parameters, ATO,ATC,etc.
7	PGAIN	signed int	/100	float	R			Present proportional gain
8	GAIN_UPPER	signed int	/100	float	R/W*			Upper gain limit
9	GAIN_LOWER	signed int	/100	float	R/W*			Lower gain limit
10	GAIN_MULT	signed int	/1000	float	R/W*			Gain multiplier
11	IGAIN	signed int	No	Integer 16	R/W*	1		Integral Gain
12	INTEGRAL_SUM	signed int	/100	float	R	-20%	20%	Integration summer in %
13	IL_OFFSET	signed int	/100	float	R/W*			Inner-loop offset
14	ALPHA_FILT	signed int	/1000	float	R/W*			Recursive filter " alpha" coefficient
15	STATUS_FLAGS	unsigned char	No	Bit String	R/W*			Status flag variable for Fieldbus
16	CMD_USED	signed int	/100	float	R	-10%	110%	Command after characterization

Continued on Page 42

**Table X: Continued from Page 41**

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt Rd					
17	FAIL_MODE	unsigned char	No	Unsigned 8	R/W*			Failure of Internal Communications on loss, set defined operation
18	PRESS_WINDOW	signed int	/100	float	R/W*	0%	100%	Window size to lock in pressure control
19	PRESS_HYST	signed int	/100	float	R/W*	0%	100%	Hyst. added to prevent window from unlocking
20	PRESS_GAIN	unsigned int	/100	float	R/W*	0	100	Gain value for pressure control
21	StrokeRate open	unsigned	/100	float	R/W	0		Opening rate limiter
22	StrokeRate close	unsigned	/100	float	R/W	0		Closing rate limiter
<b>CALIBRATION</b>								
28	CAL_FullScale	unsigned	/100	float	R/W	0	4094	Calibration full scale ADC counts minimum
29	Auto_Tune	unsigned	/100	float	R/W	0		Tuning multiplier
30	TP_ZERO	signed int	No	Integer 16	R/W*	1	4094	Top actuator 0 pressure 10-bit A/D counts
31	TP_SPAN	signed int	No	Integer 16	R/W*	1	4094	Top actuator cal. pressure 10-bit A/D counts
32	TP_FULL_SCALE	signed int	No	Integer 16	R/W*	1	4093	Top actuator span 10-bit A/D counts
33	BP_ZERO	signed int	No	Integer 16	R/W*	1	4094	Bot actuator 0 pressure 10-bit A/ counts
34	BP_SPAN	signed int	No	Integer 16	R/W*	1	4094	Bot actuator cal. pressure 10-bit A/D counts
35	BP_FULL_SCALE	signed int	No	Integer 16	R/W*	1	4093	Bot actuator span 10-bit A/D counts
36	CALIBRATE	unsigned char	No	Integer 8	R/W*			Calibration Mode setting
37	DAC_VALUE	unsigned int	No	Integer 16	R/W*	0	4095	Binary value written to 12-bit D/A

*Continued on Page 43*

Table X: Continued from Page 42

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt Rd					
38	SP_ZERO	signed int	No	Integer 16	R/W*	1	4094	Supply act. 0 press. 10-bit A/D counts
39	SP_SPAN	signed int	No	Integer 16	R/W*	1	4094	Sup. actuator cal. press. 10-bit A/D counts
40	SP_FULL_SCALE	signed int	No	Integer 16	R/W*	1	4093	Supply actuator span 10-bit A/D counts
41	FB_ZERO	signed int	No	Integer 16	R/W*	1	4094	Feedback 0% 12-bit A/D counts
42	FB_SPAN	signed int	No	Integer 16	R/W*	1	4094	Feedback 100% 12-bit A/D counts
43	FB_SCOUNT	signed int	No	Integer 16	R/W*	1	4093	Feedback full scale counts
44	PRESS_CAL	unsigned long	/100	float	R/W			Pressure applied when calibrating sensors
45	CALIBRATE_FLAGS	unsigned char	No	Bit-String	R			Error flags related to stroke calibration
46	HALL_NULL	unsigned int	No	Unsigned 16	R/W	0	1024	Hall counts when spool is in its null position
47	HALL_DOWN	unsigned int	No	Unsigned 16	R/W	0	1024	A/D Hall counts when spool is down
48	HALL_UP	unsigned int	No	Unsigned 16	R/W	0	1024	A/D Hall counts when spool is up
<b>USER SPECIFIED DATA &amp; TRAVEL DIAGNOSTICS</b>								
49	FINAL_VALUE_CUTOFF_HI	signed int	/100	float	R/W*	-15%	110%	Maximum Position Cutoff in %
50	FINAL_VALUE_CUTOFF_LO	signed int	/100	float	R/W*	-15%	110%	Minimum Position Cutoff in %
51	SOFTSTOP_HIGH	signed int	/100	float	R/W*	-10%	110%	Soft Stop High Limit in %
52	SOFTSTOP_LOW	signed int	/100	float	R/W*	-10%	110%	Soft Stop Low Limit in %
53	CYCLE_COUNTER	unsigned long	No	Unsigned 32	R/W	0	4.29x10 <sup>9</sup>	Stroke cycle counter
54	CYCLE_DEADBAND	signed int	/100	float	R/W	0	100%	Cycle counter deadband in %
55	CYCLE_LIMIT	unsigned long	No	Unsigned 32	R/W	0	4.29x10 <sup>9</sup>	Cycle counter alert limit

Continued on Page 44

*Table X: Continued from Page 43*

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt R/d					
56	TRAVEL_ENG	float	No	float	R/W	0	4.29x10 <sup>9</sup>	Valve travel accumulator in eng units
57	TRAVEL_DEADBAND	signed int	/100	float	R/W	0	100%	Travel accumulator deadband in %
58	TRAVEL_ALERT	float	No	float	R/W	0	4.29x10 <sup>9</sup>	Travel accumulator alert limit
59	STROKE_ENG	float	No	float	R/W	0	4.29x10 <sup>9</sup>	Valve stroke in eng units(inches or deg)
60	TRAVEL_UNITS	unsigned char	No	Unsigned 8	R/W	0	4.29x10 <sup>9</sup>	Code for present engineering units
61	POSALERT_HIGH	signed int	/100	float	R/W	-10%	110%	Position Alert High Limit in %
62	POSALERT_LOW	signed int	/100	float	R/W	-10%	110%	Position Alert Low Limit in %
63-68 200 -214	CURVEX (21 points)	signed int	/100	float [21]	R/W*	-10%	110%	Custom Characterization x-axis
69-74 215 -229	CURVEY (21 points)	signed int	/100	float [21]	R/W*	-10%	110%	Custom Characterization y-axis
75	TRAVEL_FLAGS	unsigned char	No	Bit Strings	R	-10%	110%	Travel alarm flags
76	POSDEV_DEADBAND	signed int	/100	float	R/W	100%	0.10%	Position Deviation Deadband
77	POSDEV_TIME	unsigned int	/10	float	R/W			Position Deviation Time in seconds
78	SIG_START	signed int	/100	float	R/W	-10%	110%	Signature Starting Command in %
79	SIG_STOP	signed int	/100	float	R/W	-10%	110%	Signature Stopping Command in %
80	RAMP_RATE	unsigned char	300/	float	R/W	>1		Ramping time in %/minute
81	STEP_TIME	unsigned int	/100	float	R/W	0 sec.	650 sec.	Settling time after step in seconds
82	SIG_FLAGS	unsigned char	No	Unsigned 8	R/W			Signature Flags
83	SAMPLE_TIME	unsigned char	/100	float	R/W	0.1 sec		Sampling time in seconds

*Continued on Page 45*

Table X: Continued from Page 44

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt Rd					
84	SIG_COUNTER	unsigned int	No	Unsigned 16	R/W			Number of collected sample points
<b>INTERNAL DIAGNOSTICS</b>								
90	INTAD_RAW1	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D temperature counts
91	INTAD_RAWTP	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D counts.top actuator pres
92	INTAD_RAWBP	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D counts.bot actuator pres
93	INTAD_RAWSP	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D counts.supply pressure
94	INTAD_RAW3	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D 2.5VDC Ref counts
95	INTAD_RAW4	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D IL hall sensor counts
96	INTAD_RAW5	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D 12-bit DAC output
97	INTAD_RAW6	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D modulator current counts
98	INTAD_RAW8	unsigned int	No	Unsigned 16	R	0	4095	10-bit A/D zero ref. counts
99	TEMPERATURE	signed int	No	Integer 16	R			Temperature, reported in TEMPunit
100	Port_1 (Port 1)	signed long int	/100	float	R			Port 1 pressure in PRESSunit
101	Port_2 (Port 2)	signed long int	/100	float	R			Port 2 pressure in PRESSunit
112	TEST_MODE	unsigned char	No	Unsigned 8	R/W*			Off line tests and enable diagnostic update
<b>MISCELLANEOUS FIELDBUS FUNCTIONS</b>								
NA	SIG_INDEX	NA	NA	Unsigned 16	R/W*			Pointer used for data transition
NA	SIG_DATA	NA	NA	float [4]	R			Array of signature data. Order of data is: Command, position, port 2 / 1port 1 pressure

Continued on Page 46

Table X: Continued from Page 45

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt Rd					
NA	MFG_PHONE	NA	NA	Visible String	R/W			Manufacturer's phone number field
NA	PUR_ORDER_NUM	NA	NA	Visible String	R/W			Purchase order number field
NA	GENERIC_PARM_NUM	NA	NA	DS-66	R/W			Input point for desired Logix variable
NA	GENERIC_PARM_VAL	NA	NA	Unsigned 32	R/W			Data for selected Logix variable
NA	BLOCK_TEST	NA	NA	Unsigned0d 8 [8]	R/W			Special diagnostics array
102	SUPPLY_PRESSURE	signed long int	/100	float	R			Air supply pressure in PRESSunits
103	VOLT_REFERENCE	signed int	/1000	float	R			12-bit A/D, 2.5VDC reference (Volts)
104	HALL_SENSOR	signed int	/1000	float	R			Inner-loop hall sensor output (Volts)
105	DAC_CHECK	signed int	/1000	float	R			12-bit D/A output (Volts)
106	MOD_CURRENT	signed int	/100	float	R			Modulator piezo voltage (VDC)
107	IL_CHK	signed int	R	Integer 16				Inner-loop check
108	INTERVAL_FLAGS	unsigned char	No	Bit String	R			internal errors related to electronics
109	PRESS_FLAGS	unsigned char	No	Bit String	R			error flags related to the pressure sensors
110	PRESS_UNITS	unsigned char	No	Unsigned 8	R/W			Units user wants reported for press
111	TEMP_UNITS	unsigned char	No	Unsigned 8	R/W			Units user wants reported for temperature
<b>VALVE, ACTUATOR, AND POSITIONER INFORMATION</b>								
130	VALVE_MAN_ID	unsigned char	No	Unsigned 32	R/W			Valve manufacturer
131	VALVE_TYPE	unsigned char	No	Unsigned 8	R/W			Valve type
132	VALVE_SIZE	unsigned char	No	Unsigned 8	R/W			Valve size in inches

Continued on Page 47

Table X: Continued from Page 46

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt Rd					
133	VALVE_CLASS	unsigned char	No	Unsigned 8	R/W			Pressure class rating
134	VALVE_ENDCON	unsigned char	No	Unsigned 8	R/W			Valve end connections
135	VALVE_BODYMA	unsigned char	No	Unsigned 8	R/W			Valve body material
136	VALVE_TRIMMAT	unsigned char	No	Unsigned 8	R/W			Valve trim material
137	VALVE_TRIMCHAR	unsigned char	No	Unsigned 8	R/W			Valve trim characteristic
138	VALVE_TRIMTYPE	unsigned char	No	Unsigned 8	R/W			Valve trim type
139	VALVE_TRIMNO	unsigned char	No	Unsigned 8	R/W			Valve trim diameter
140	VALVE_PACKTYPE	unsigned char	No	Unsigned 8	R/W			Valve packing type
141	STROKE_OPENTIM	unsigned int	/100	float	R/W			Stroke open time in seconds
142	STROKE_CLOSEDTIM	unsigned int	/100	float	R/W			Stroke closed time in seconds
143	STROKE_TSTPSI	signed int	/100	float	R			Pressure
144	STEM_DIAM	float	No	float	R/W			Stem/shaft diameter
145	LEAK_CLASS	unsigned char	No	Unsigned 8	R/W			Shutoff leakage class
146	INLET_PRESS	float	No	float	R/W			Upstream pressure of valve
147	OUTLET_PRESS	float	No	float	R/W			Downstream pressure of valve
148	VALVE_FLAGS	unsigned char	No	Unsigned 8	R/W			Valve information (Ex. Flow direction)
149	RATED_TRAV	float	No	float	R/W			Rated valve travel before needs service
150	ACT_MAN_ID	unsigned char	No	Unsigned 32	R/W			Actuator manufacturer
151	ACT_TYPE	unsigned char	No	Unsigned 8	R/W			Actuator type

Continued on Page 48

Table X: Continued from Page 47

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt Rd					
152	ACT_SIZE	unsigned char	No	Unsigned 8	R/W			Actuator size
153	SPRING_TYPE	unsigned char	No	Unsigned 8	R/W			Spring type: single, dual, etc.
154	SPOOL_ID	unsigned char	No	Unsigned 8	R/W			Spool identification
155	ELECTRONICS_SN	unsigned char	No	Visible String	R/W*			Electronics serial number
156	SOFTWARE_VER	unsigned int	No	Unsigned 16	R/W			Positioner embedded code version
157	VALVE_SN	unsigned char	No	Visible String	R/W			Valve serial number
158	PO_DATE	unsigned char	No	Visible String	R/W			PO date

Continued on Page 49



Table X: Continued from Page 48

Variable No.	Variable	Logix Positioner		Fieldbus Datatypes	R/W	Low Limits	Up Limits	Description
		Type	Fix Pt Rd					
158	INSTALL_DATE	unsigned char	No	Visible String	R/W			Installation date
<b>MISCELLANEOUS COMMANDS</b>								
171	LOAD_EE_DEFAULTS	unsigned char	No	Unsigned 8	R/W*			EEPROM write mode
172	ENG_RELEASE_NUM	unsigned int	No	Unsigned 8	R			Embedded engineering release number
173	MISC_FLAGS	unsigned char	No	Unsigned 8	R/W*			Miscellaneous Flags, Quick-Cal Enable/Disable, Large actuator
<b>DATA FORMAT</b>								
	signed/unsigned characters	1 byte	Available on both Standard and Advanced					
	signed/unsigned integers	2 bytes	Advanced models only					
	signed/unsigned long integers	4 bytes						
	float (4 bytes)	IEEE-754						
<b>READ/WRITE</b>								
	R= Read only							
	R/W= Read/Write access							
	R/W* = Transducer block must be out of service to write							

## 8 Maintenance and Repair

### 8.1 Driver Module Assembly

The driver module assembly moves the spool valve by means of a differential pressure across its diaphragm. Air is routed to the driver module from the regulator through a flexible hose. A barbed fitting connects the flexible hose to the driver module assembly. Wires from the driver module assembly connect the hall effect sensor and the piezo valve modulator to the main PCB assembly.

#### Driver Module Assembly Replacement

To replace the driver module assembly, refer to Figures 11-15 and 25 and proceed as outlined below. The following tools are required:

- Flat plate or bar about 1/8" thick
- Phillips screwdriver
- 1/4" nutdriver

**WARNING:** Observe precautions for handling electrostatically sensitive devices.

Figure 11: Driver Module Assembly






Figure 13: Spool Valve Cover Assembly




1. Make sure the valve is bypassed or in a safe condition.
2. Disconnect the power and air supply to the unit.
3. Remove the driver module cover (Figure 15), using a flat bar or plate in the slot to turn the cover.
4. Remove the spool valve cover by removing the screw and sliding the cover assembly backwards until the tab is clear of the slot (Figure 13). The sheet metal cap, hydrophobic filter, and O-ring should be removed with the spool valve cover. It is not necessary to take these parts out of the spool valve cover.
5. Being careful not to lose the nylon washer, remove the Phillips-head screw that attaches the driver module to the main housing (Figure 14).

Figure 14: Spool and Block




- ⚠ **WARNING:** Spool (extending from the driver module assembly) is easily damaged. Use extreme caution when handling spool and spool valve block. Do not handle the spool by the machined portions of spool. The tolerances between the block and spool are extremely tight. Contamination in the block or on the spool may cause the spool to hang.

Figure 15: Driver Module Barbed Fitting



6. Remove the spool valve block by removing the two Phillips-head screws and carefully sliding the block off the spool (Figure 14).
7. Carefully remove the spool by sliding the end of the spool out of the connection clip. Excessive force may bend spool.
8. Remove the main cover.
9. Remove the plastic board cover by removing the three retaining screws (see Figure 16).
10. Disconnect the flexible tubing from the barbed fitting at the driver module assembly (see Figure 15).
11. Use the 1/4" nutdriver to remove the barbed fitting from the driver module assembly.
12. Unplug the two wiring connections that link the driver module assembly to the main PCB assembly.
13. Feed the two wires on the driver module back into the driver module compartment so that they stick out the driver module opening (see Figure 12). This will allow the driver module to thread out without tangling or cutting the wires.
14. Grasp the base of the driver module and turn it counterclockwise to remove. After it is threaded out, carefully retract the driver module from the housing.

Figure 16: Main PCB Assembly



15. Remove the barbed fitting from the side of the new driver module using the 1/4" nutdriver.
16. Verify that the O-ring is in place on the top of the new driver module. Lay the wires back along the side of the driver module as shown in Figure 12 and hold the wires in position by hand.
17. Gently insert the driver module into the driver module compartment in the housing. Turn the driver module clockwise to thread it into the housing. Continue rotating the driver module until it bottoms out.
18. Once the driver module has bottomed out so that the threads are fully engaged, rotate the driver module counter clockwise until the flat on the driver module and the flat on the housing are aligned. This will align the screw hole for the next step.
19. Verify that the nylon gasket is in the counter bore in the driver module retaining screw hole as shown in Figure 14.

20. Insert a driver-to-housing screw into the driver housing through the counterbored hole in positioner main housing. Tighten with a Phillips screwdriver.
21. Reach through the main compartment into the driver module compartment of the positioner and install the barbed fitting on the side of the driver module using the ¼" nutdriver.

**NOTE:** Do not mix the barbed fitting with those from older Logix positioners. Older models contain orifices that will not work in the Logix 3400IQ model. Orifices are brass-colored, barbed fittings are silver-colored.

22. Reconnect the flexible tube coming from the regulator to the barbed fitting.
23. Feed the driver module wires into the main chamber of the housing, and connect them to the main PCB Assembly.
24. Verify that the three O-rings are in the counterbores on the machined platform where the spool valve block is to be placed (Figure 22).
25. Carefully slide the spool into the connecting clip on the top of the driver module assembly.
26. Carefully slide the block over the spool, using the machined surface of the housing base as a register (Figure 14). Slide the block toward the driver module until the two retaining holes line up with the threaded holes in the base.
27. Install two spool-valve screws and tighten securely with a Phillips screwdriver (see Figure 14).
28. Slide the spool valve cover assembly over the spool valve until the tang engages into the housing slot. Install spool valve cover screw and tighten securely (see Figure 13).
29. Install the plastic board cover. Insert the three retaining screw through the plastic cover into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten (see Figure 16).
30. Reconnect power and air supply to the positioner and perform a stroke calibration.
31. Reinstall all covers.


## 8.2 Regulator

The regulator reduces the pressure of the incoming supply air to a level that the driver module can use.

### Replacing Regulator

To replace the regulator, refer to Figures 11 and 15 and proceed as outlined below. The following tools are required:

- 54**
- Phillips screwdriver
  - ¼" nutdriver

 **WARNING:** Observe precautions for handling electrostatically sensitive devices.

1. Make sure valve is bypassed or in a safe condition.
2. Disconnect the power and air supply to the unit.
3. Remove the main cover.
4. Remove the plastic board cover by removing the three retaining screws (see Figure 16).
5. Remove the retaining screw from the main PCB assembly.
6. Remove the five wire connections from the main PCB assembly and lift the main PCB out of the housing.
7. Remove the four screws from the regulator base. Verify that as regulator is removed, the O-ring and filter remain in the counter-bore.
8. Remove tubing and barbed fitting from the regulator base.
9. Install barbed fitting and tubing to the new regulator.
10. Verify O-ring and filter are in the counterbore. Install new regulator using 8-32 x ½" screws.

**NOTE:** Do not mix the regulator with those from older Logix positioners. Older models contain regulators with different settings that will not work in the Logix 3400IQ model. The regulator pressure setting is printed on the top of the regulator. The Logix 3400IQ regulator is set to 17.4 psig.

11. Reinstall the five wire connections.
12. Install the main PCB into the housing. Insert the retaining screw through the board into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten.
13. Install the plastic board cover. Insert the three retaining screws through the plastic cover into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten (see Figure 16).
14. Reinstall all covers.


### 8.3 Checking or Setting Internal Regulator Pressure

To check or set the internal regulator pressure, refer to Figure 17 and proceed as outlined below. The tools and equipment used in the next procedure are from indicated vendors. The following tools are required:

- Calibrated pressure gauge (0 to 30 psi)
- ¼" flexible tubing
- Barbed Tee (Clippard Minimatic part number T22-2 or equivalent)
- ⅜" Allen wrench
- ⅜" open-end wrench

**WARNING:** Observe precautions for handling electrostatically sensitive devices.

Figure 17: Driver Module Regulator Pressure Check



1. Make sure the valve is bypassed or in a safe condition.
2. Remove the main cover.
3. Remove the plastic board cover by removing the three retaining screws.
4. Remove the 1/16" flexible tubing from the barbed fitting on the side of the driver module.
5. Obtain a barbed tee and two pieces of 1/16" flexible tubing, a few inches in length each.
6. Position the barbed tee between the internal regulator and the driver module by connecting the 1/16" flexible tubing, found in the positioner, to one side of the barbed tee. Using one of the new flexible tubing pieces, connect the barbed tee to the barbed fitting on the side of the driver module. Connect the remaining port on the barbed tee to a 0 to 30 psi pressure gauge.
7. Reconnect the air supply to the positioner and read the internal regulator pressure on the 0 to 30 psig gauge. The internal pressure should be set to 17.4 ±0.2 psig. If adjustment is needed, loosen the set screw retaining nut on the top of the regulator using the 3/8" open-end wrench. Then adjust the regulator pressure by turning the set screw on the top of the regulator with the 3/32" Allen wrench.
8. Once the regulator pressure is set, tighten the set screw retaining nut on the top of the regulator, remove the air supply to the positioner, remove the barbed tee, and reconnect the flexible tubing from the regulator to the barbed fitting on the side of the driver module.



9. Install the plastic board cover. Insert the three retaining screws through the plastic cover into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten (see Figure 16).
10. Reinstall all covers.

## 8.4 Spool Valve

The spool valve routes the supply air to one side of the actuator while venting the opposite side (see Figure 1). The position of the spool valve is controlled by the driver module.

### Replacing the Spool Valve

To replace the spool valve, refer to Figures 12, 14 and 21 and proceed as outlined below. The following tools are required:

- Phillips screwdriver

1. Make sure the valve is bypassed or in a safe condition.
2. Disconnect the power and air supply to the unit.
3. Remove the spool valve cover by removing the screw and sliding the cover assembly backwards until the tab is clear of the slot. It is not necessary to remove the sheet metal cap, hydrophobic filter, or O-ring from this assembly (Figure 18).

**⚠ WARNING:** The spool (extending from the driver module assembly) is easily damaged. Use extreme caution when handling spool and spool valve block. Do not handle the spool by the machined portions of spool. The tolerances between the block and spool are extremely tight. Contamination in the block or on the spool may cause the spool to hang.

4. Remove the spool valve block by removing the two Phillips-head screws and carefully sliding the block off the spool (Figure 14).
5. Carefully remove spool by sliding end of spool out of connecting clip. Excessive force may bend the spool.
6. Verify that the three O-rings are in the counterbores on the machined platform where the new spool valve block is to be placed (Figure 22).
7. Carefully slide the spool into the connecting clip of the driver module assembly.
8. Carefully slide the block over the spool, using the machined surface of the housing base as a register (Figure 14). Slide the block toward the driver module until the two retaining holes line up with the threaded holes in the base.
9. Install two spool valve screws and tighten securely with a Phillips screwdriver (see Figure 14).

10. Slide the spool valve cover assembly over the spool valve until the tang engages into the housing slot. Install the spool valve cover screw and tighten securely (see Figure 13).
11. Reconnect power and air supply to the positioner and perform a stroke calibration.

## 8.5 Spool Valve Cover


The spool valve cover incorporates a hydrophobic filter element in a two-piece cover. This protects the spool valve chamber from dirt and moisture and provides a low back pressure vent for exhaust air from the spool valve.

### Replacing Filter in Spool Valve Cover

To replace the filter in the spool valve cover, refer to Figures 12 and 17 and proceed as outlined below. The following tools are required:

- Phillips screwdriver
1. Remove the spool cover by removing the screw and sliding the cover assembly backwards until the tab is clear of the slot. The sheet metal cover may be removed and cleaned with a brush or by blowing out with compressed air (Figure 13).
  2. Remove the O-ring from around the hydrophobic filter element and set aside (Figure 18).
  3. Remove the molded filter element by pulling it straight out of the chamber cover vent piece.
  4. Install O-ring into base of chamber cover vent piece as shown in Figure 18.
  5. Place new molded filter element into the chamber cover vent piece. This filter element provides part of the track to secure the O-ring installed in the last step.
  6. Place spool valve shroud onto spool valve cover.
  7. Place the spool valve cover assembly in place by setting it on the ramp and sliding it until the tab seats in the slot (Figures 12 and 17) and secure with a 8-32 screw.

Figure 18: Spool Valve Cover Assembly




## 8.6 Stem Position Sensor

The position feedback assembly transmits valve positions information to the processor. This is accomplished by means of a rotary position sensor that connects to the valve stem through a feedback linkage. To provide for accurate tracking of the pin in the slot, the follower arm is biased against one side of the slot with a rotary spring. This spring also automatically moves the position feedback assembly to its limit in the unlikely event of failure of any component in the linkage.

### Stem Position Sensor Replacement


To replace the stem position sensor, refer to Figure 16, 19 and 22 and proceed as outlined below. The following tools are required:

- Phillips screwdriver

 **WARNING:** Observe precautions for handling electrostatically sensitive devices.

1. Make sure the valve is bypassed or in a safe condition.
2. Disconnect the power and air supply to the unit.
3. Remove the main cover.
4. Remove the plastic board cover by removing the three retaining screws (see Figure 16).
5. Disconnect the position sensor wires from the main PCB assembly.
6. Remove the two rotary position sensor-retaining screws and lift the sensor out of the housing.
7. Turn the new position sensor shaft until the dot on the side of the shaft is aligned with the wires on the side of the position sensor (Figure 19).
8. Insert the position sensor into the shaft with the wires pointing toward the main PCB assembly. Turn the position sensor clockwise until bolting slots align with the housing screw holes and the wires on the sensor protrude over the main PCB assembly.  
  
**NOTE:** Do not mix the position sensor with those from older Logix positioners. Older models contain sensors with different ranges that will not work in the Logix 3400IQ model. The wires on the Logix 3400IQ position sensor are red, white and black.
9. Carefully center the position sensor on the shaft bore, insert and tighten the screws. Do not overtighten.
10. Route the wires along the side of the position sensor and reconnect to the main PCB assembly.
11. Install the plastic board cover. Insert the three retaining screws through the plastic cover into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten (see Figure 16).
12. Reinstall all covers.
13. Reconnect power and air supply to the positioner and perform a stroke calibration.

Figure 19: Stem Position Sensor Orientation



## 8.7 Main PCB Assembly

The main printed circuit board (PCB) assembly contains the circuit boards and processors that perform control functions of the positioner. The main PCB is to be replaced as a unit. None of the components on the main PCB are serviceable. It consists of a controller board and a Fieldbus communication board.

### Replacing Main PCB Assembly

To replace the main PCB assembly, refer to Figure 12 and 16 and proceed as outlined below. The following tools are required:

- Phillips screwdriver



**WARNING:** Observe precautions for handling electrostatically sensitive devices.

1. Make sure the valve is bypassed or in a safe condition.
2. Disconnect the power and air supply to the unit.
3. Remove the main cover.

4. Remove the plastic board cover by removing the three retaining screws (see Figure 16).
5. Remove the retaining screw from the main PCB assembly.
6. Remove the five wire connections from the main PCB assembly and lift the main PCB out of the housing (see Figure 16).
7. Reinstall the five wire connections (see Figure 12) on the new main PCB.
8. Install the new main PCB into the housing. Insert the retaining screw through the board into the threaded boss and tighten, using a Phillips screwdriver. Do not over tighten.
9. Install the plastic board cover. Insert the three retaining screws through the plastic cover into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten (see Figure 16).
10. Reinstall all covers.
11. Reconnect power and air supply to the positioner and reconfigure the positioner being sure to perform a stroke calibration.

## 8.8 Pressure Sensor Board


On advanced model Logix 3400IQ positioners, a pressure sensor board is installed in the positioner. The pressure sensor board contains two pressure sensors that measure the pressure on output ports 1 and 2. The main PCB electronics automatically senses the presence of the pressure sensor board. If present, the actuator pressure sensors are used in the positioner control algorithm to enhance valve stability. For optimal performance, the actuator pressure sensors need to be calibrated. The actuator pressure sensor calibration is performed using a 375 Handheld Communicator or Host configuration software.

In the standard model, the pressure sensor board is replaced by a plate that plugs the actuator pressure sensor ports. This plate can be replaced by a pressure sensor board to field-upgrade a standard model to an advanced model.

### Removing the Pressure Sensor Board (Advanced Model)

To replace the pressure sensor board, refer to Figures 11, 15 and 21 and proceed as outlined below. The following tools are required:

- Phillips screwdriver

 **WARNING:** Observe precautions for handling electrostatically sensitive devices.

1. Make sure the valve is bypassed or in a safe condition.
2. Disconnect the power and air supply to the unit.
3. Remove the main cover.
4. Remove the plastic board cover by removing the three retaining screws (see Figure 16).

5. Disconnect the ribbon cable on the pressure sensor board from the PCB assembly (see Figure 12). Lifting the main board may make this easier.
6. Remove the two screws holding the pressure sensor board to the housing. Lift the metal stiffener plate off the pressure sensor board and set aside for future use.
7. Remove the pressure sensor board.

### Removing the Pressure Sensor Plug Plate (Standard Model)


To upgrade a standard model to an advanced model, the pressure sensor plug plate must be removed and replaced by a pressure sensor board. The main PCB electronics automatically senses the presence of the pressure sensor board. If present, the actuator pressure sensors are used in the positioner control algorithm to enhance valve stability. For optimal performance, the actuator pressure sensors need to be calibrated. The actuator pressure sensor calibration is performed using a Handheld Communicator or host configuration software. To upgrade a standard model to an advanced model, refer to Figures 11, 15 and 21 and proceed as outlined below. The following tools are required:

- Phillips screwdriver
1. Make sure the valve is bypassed or in a safe condition.
  2. Disconnect the power and air supply to the unit.
  3. Remove the main cover.
  4. Remove the plastic board cover by removing the three retaining screws (see Figure 16).
  5. Remove the two screws holding the pressure sensor plug plate to the housing. Lift the metal stiffener plate off the pressure sensor plug plate and set aside for future use.
  6. Remove the pressure sensor plug plate and discard.

### Installing the Pressure Sensor Board (Advanced Model)

The pressure sensor board is installed on the advanced model only. To install the pressure sensor board, refer to Figures 11, 15 and 25 and proceed as outlined below. The following tools are required:

- Phillips screwdriver
- Torque wrench

 **WARNING:** Observe precautions for handling electrostatic sensitive devices.

1. Verify that the two pressure sensor O-rings (item 15) are in place in the housing.
2. Set the pressure sensor board assembly in place so that the O-rings make contact with the faces of the pressure sensors.
3. Place the metal stiffener plate (item 12) on top of the pressure sensor board over the pressure sensors and align the two holes in the pressure sensor plate with the threaded bosses in the housing.

4. Insert two screws through the stiffener plate and pressure sensor board into the threaded holes in the housing and tighten evenly, to 8 in-lb.
5. Connect the ribbon cable on the pressure sensor board to the main PCB assembly.
6. Install the plastic board cover. Insert the three retaining screws through the plastic cover into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten.
7. Reinstall all covers.
8. Reconnect power and air supply to the positioner. Use the Host software or a handheld communicator to perform a pressure sensor calibration.


## 8.9 User Interface Board

The user interface board provides a connection point inside the explosion-proof housing for all hookups to the positioner.

### Replacing the User Interface Board

To replace the user interface board, refer to Figures 6, 11, 15 and 25 and proceed as outlined below. The following tools are required:

- Phillips screwdriver

 **WARNING:** Observe precautions for handling electrostatic sensitive devices.

1. Make sure the valve is bypassed or in a safe condition.
2. Disconnect the power and air supply to the unit.
3. Remove the main cover.
4. Remove the plastic board cover by removing the three retaining screws (see Figure 16).
5. Remove the retaining screw from the main PCB assembly and lift the main PCB out of the housing (see Figure 16). It is not necessary to disconnect all of the wires, only the UI plug.
6. Remove the user interface cover.
7. Disconnect the field wiring from the user interface board terminals and remove the three screws that hold the user interface board in the housing (see Figure 6).
8. Remove the user interface board, carefully pulling the wiring through the bore.
9. Verify that the O-ring is in place in the counterbore in the positioner housing, or on the plug on the back of the UI tray.
10. Feed the wires on the back of the new user interface board through the passageway into the main chamber of the housing.
11. Set the user interface board in place and secure with three screws (see Figure 6).

12. Reconnect the field wiring to the user interface board terminals.
13. Install the main PCB into the housing. Insert the retaining screw through the board into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten.
14. Install the plastic board cover. Insert the three retaining screws through the plastic cover into the threaded boss and tighten evenly, using a Phillips screwdriver. Do not overtighten (see Figure 16).
15. Reinstall the UI wire connection (see Figure 12).
16. Reinstall all covers.

## 9 Optional Vented Design

**NOTE:** See Figures 19 and 20

A standard Logix 3400IQ positioner is vented directly to the atmosphere. When supply air is substituted with sweet natural gas, piping must be used to route the exhausted natural gas to a safe environment. This piping system may cause some positioner back pressure in the main chamber (from the modulator and regulator) and spool chamber (from the actuator). Back pressure limitations are described below.

Two chambers must be vented on the Logix 3400IQ positioners: the main housing chamber and the spool valve chamber (Figures 20 and 21). The main chamber vent is located on the backside of the positioner (see Figure 20). Vented-design Logix 3400IQ positioners are supplied from the factory with a fitting installed in the main chamber vent. Connect the necessary tubing/piping to this fitting to route the exhausted natural gas to a safe environment.

The maximum allowable back pressure from the collection device on the main housing vent is 2.0 psig (0.14 barg). Vent flow rate is 0.5 std ft<sup>3</sup>/min (1.4 std liter/min).

**⚠ WARNING:** The back pressure in the main housing must never rise above 2.0 psig (0.14 barg).



Figure 20: Main Housing Vent






Figure 21: Spool Cover Vent



The spool valve chamber (see Figure 21) must also be vented through the spool valve cover. Vented-design Logix 3400IQ positioners are supplied from the factory with a fitting installed in the spool valve cover (item SKU 179477). Connect the necessary tubing/piping to this fitting to route the exhausted natural gas to a safe environment. The maximum allowable back pressure in the spool valve chamber is 8 psig (0.55 barg). Pressures greater than 8 psig will cause vented gas to leak past the spool cover O-ring to the atmosphere and will result in overshoot of the positioner.

*Figure 22: Exploded Drawing*

## 10 Parts List

Table XI: Parts

Item No.	Part	Item No.	Part
1	Housing Logix 3000IQ Positioner	28	Threaded Plug
2	Main Housing Cover	29	Main Vent Cover
3	O-ring, Main Housing Cover	30	Screw, Main Vent Cover
4	Screw, Anti-rotation	31	Driver Module Cover
5	Plastic Main PCB Cover	32	O-ring, Driver Module Cover
6	Screw, Main PCB Cover Short (2)	33	Driver Module Assembly
7	Screw, Main PCB Cover Long	34	Hex Barbed Fitting with Captive O-ring
8	Main PCB Assembly	35	Flexible Tubing
9	Screw, Main PCB Assembly Retaining	36	Screw, Driver to Housing
11	Screw, Pressure Sensor Board (2)	37	Nylon Washer
12	Pressure Sensor Board Stiffener	38	Spool Valve
13	Pressure Sensor Board (Advanced Only)	39	Spool Valve Block
14	Pressure Sensor Plug Plate (Standard Only)	40	Screw, Spool Valve to Housing (2)
15	O-ring, Pressure Sensor to Housing (2)	41	O-ring, Spool Valve (3)
16	Pressure Regulator, 5 to 30 psig (Includes 2 O-rings)	42	Screw, Spool Valve Cover
17	Screw, Regulator Plate to Housing (4)	43	Spool Valve Shroud
18	Hex Barbed Fitting with Captive O-ring	44	Spool Valve Cover
19	Internal Filter	45	Hydrophobic Filter, Spool Valve Chamber
20	O-ring, Interface Plate to Housing Seal	46	O-ring, Spool Valve Cover
21	Customer Interface Cover	47	Pressure Gauge, 0-160 psig (2)
22	O-ring, Customer Interface Cover	48	Air Screen (3)
23	Screw, Anti-rotation	49	Screw, Position Feedback Potentiometer to Housing (2)
24	Screw, User Interface Board (3)	50	Metal Washer (2)
25	User Interface Board Potted Assembly	51	Position Feedback Potentiometer
26	O-ring, User Interface Board	52	Feedback Shaft
27	Grounding Screw (2)	53	Screw, Spring to Feedback Shaft
		54	O-ring, Feedback Shaft
		55	Torsion Spring
		56	E-ring

## 11 Logix 3400IQ Spare Parts Kits

(See Figure 22 for item numbers.)

Table XII: Spare Parts Kits

Item No.	Description	Quantity
Kit 2: Driver Module Assembly -40° to 80°C Kit, P/N 199786.999.000		
16	Pressure Regulator	1
17	Screw, Regulator to Housing	4
33	Driver Module Assembly	1
34	Hex Barbed Fitting w/ Captive O-ring	1
36	Screw, Driver to Housing	1
37	Nylon Washer	1
Kit 3: Spool Assembly Valve Kit, P/N 199787.999.000		
38	Spool	1
39	Spool Valve Block	1
40	Screw, Spool Valve to Housing	2
41	O-ring, Spool Valve	3
Kit 4: Pressure Regulator, P/N 215814.999.000		
16	Pressure Regulator with Captive O-rings	1
17	Screw, Regulator to Housing	4

Item No.	Description	Quantity
Kit 5: Feedback Shaft Kit, P/N 199788.999.000		
52	Feedback Shaft	1
53	Screw, Spring to Feedback Shaft	1
54	O-ring, Feedback Shaft	1
55	Torsion Spring	1
56	E-ring	1
Kit 6: Feedback Shaft Kit (NAMUR), P/N 218814.999.000		
52	Feedback Shaft	1
53	Screw, Spring to Feedback Shaft	1
54	O-ring, Feedback Shaft	1
55	Torsion Spring	1
56	E-ring	1

Item No.	Description	Quantity
<b>Kit 7: Soft Goods Kit, P/N 199789.999.000</b>		
3	O-ring, Main Housing Cover	1
15	O-ring, Pressure Sensor to Housing	2
20	O-ring, Regulator to Housing	1
22	O-ring, User Interface Cover	1
26	O-ring, User Interface Board	1
35	Flexible Tube	1
37	Nylon Washer	1
41	O-ring, Spool Valve to Housing	3
45	Hydrophobic Filter, Spool Valve Chamber	1
46	O-ring, Spool Valve Cover	1
54	O-ring, Feedback Shaft	1
<b>Kit 8: Standard Model Pressure Sensor Plug Plate Kit, P/N 199790.999.000</b>		
11	Screw, Pressure Sensor Board	2
14	Pressure Sensor Plug Plate	1
15	O-ring, Pressure Sensor to Housing	2

Item No.	Description	Quantity
<b>Kit 9: Advanced Model Pressure Sensor Board Kit, P/N 199791.999.000</b>		
11	Screw, Pressure Sensor Board	2
13	Pressure Sensor Board	1
15	O-ring, Pressure Sensor to Housing	2
<b>Kit 10: Main PCB Assembly Kit, P/N 230226.999.000</b>		
6	Screw, Main PCB Cover Short	2
7	Screw, Main PCB Cover Long	1
8	Main PCB	1
9	Screw, Main PCB Retaining Screw	1
<b>Kit 11: User Interface Board Kit, P/N 230227.999.000</b>		
24	Screw, User Interface to Housing	3
25	User Interface Board	1
26	O-ring, User Interface Board	1
<b>Kit 13: Position Feedback Potentiometer Kit, P/N 199794.999.000</b>		
49	Screw, Feedback Potentiometer to Housing	2
50	Metal Washer	2
51	Position Feedback Potentiometer	1

## 12 Logix 3400IQ Mounting Kits

### 12.1 Valtek Mounting Kits

Table XIII: Valtek Linear Mounting Kits

Spud	25 in <sup>2</sup>		50 in <sup>2</sup> *		100-200 in <sup>2</sup>	
	Standard	Handwheel	Standard	Handwheel	Standard	Handwheel
2.00	164432	164433	164434	164433		
2.88			164435	164436	164437**	164436
3.38					164437	164438
4.75					164439	164440

\* A 50 square", 2.00 spud with live loading requires kit number. \*\* Live-loading is not available on a 100 in<sup>2</sup>, 2.62 spud.

Table XIV: Valtek Rotary Mounting Kits\*

Spud	25 in <sup>2</sup>		50 in <sup>2</sup> *		100-200 in <sup>2</sup>	
	Standard	Optional	Standard	Optional	Standard	Optional
0.44	135429	135432	135430	135431		
0.63	135429	135437	135430	135433	135431	
0.75	135429	135438	135430	137212	135431	
0.88	135429	135439	135430	137213	135431	135434
1.12	135429		135430	137214	135431	137215
1.50	135429		135430		135431	137216
1.75	135429		135430		135431	137217

\* Standard: All rotary valves with standard accessories (end of shaft mount). Optional: All rotary valves with handwheels or volume tanks (linkage design).

## 12.2 Logix O.E.M. Mounting Kits

Table XV: Logix O.E.M. Mounting Kits

Brand	Model	Size	Mounting Kit	
Fisher	657 & 667	30	213905	0.5" – 1.5" stroke
		34	141410	
		40		
		50	171516	0.5" – 1.5" stroke
			171517	2" stroke
		60	171516	0.5" – 1.5" stroke
			171517	2" stroke
	70	171518	4" stroke	
	1250	225	173371	
		450		
		675		
1052	33	171549	Rotary	
657-8	40	173798		
Neles	RC		171512	
	RD		178258	
Foxboro	Slid-Std		173567	
	Linear		178258	
Honeywell	VST-VA3R	17-in. dia.	173798	
	VSL-VA1D	12-in. dia.	173798	

Continued on page 72

Table XV: Logix O.E.M. Mounting Kits (continued)

Brand	Model	Size	Mounting Kit	
Masonellan (Linear Actuators)	37	9	171721	
		11		
		13	171720	
		18	173382	
		24	173896	
	38	11	173235	
		13	173234	
		15	186070	
		18	173382*	
		24	173896	
	71 Domotor	25	173325	
		50	173335	
		100	173336	
	88	6	171722	
		16	173827	
	47	B	173361	
	48	B	173361	
"D" Domotor	200	175141		
71-2057AB-D		176179		
71-40413BD		176251		
Masonellan (Rotary Actuators)	33	B	173298	
	35	4	173298	
		6		
		7		
70	10	173298		
Valtek	Trooper	166636	0.75" – 1.50" Std	
Automax	R314	141180	HD	
	SNA115	NK313A		

Continued on page 73



Table XV: Logix O.E.M. Mounting Kits (continued)

Brand	Model	Size	Mounting Kit
Vanguard	37/64		175128
Air-Torque	AT Series	AT0 – AT6	Consult factory
Automax	SNA Series	SNA3 – SNA2000	
	N Series	N250.300	
Bettis	R Series	R2 – R5	
	RPC Series	RP – TPC11000	
EL-O-Matic	G Series	G2009-M11 – G3020-M11	
	E Series	E25 – E350	
Hytork	P Series	P35 – P4000	
	XL Series	XL45 – XL4580	
Unitorq	M Series	M20 – M2958	
Worcester	39 Series	2539 - 4239	

\*Adjustable mounting kit 173798 may be needed if handwheels are used.

## 12.3 NAMUR Accessory Mounting Kit Part Numbers

Use prefix “NK” and choose bracket and bolt options from the following table.

Table XVI: NAMUR Accessory Mounting Kit Part Numbers

Bracket Option	Description
28	20 mm pinion x 80 mm bolt spacing
28	38 mm pinion x 80 mm bolt spacing
313	30 mm pinion x 80 mm bolt spacing
513	50 mm pinion x 130 mm bolt spacing
Bolt Option	Description
A	10-24 UNC bolting
B	10-32 UNF bolting
L	M5-.8 metric bolting

Example: NK313A, NAMUR Accessory Mounting Kit with 30 mm pinion x 80 mm bolt spacing and 10-24 UNC bolting.

## 13 Frequently Asked Questions

**Q: I set the Final Value Cutoff Low at 5 percent. How will the positioner operate?**

A: Assume that the present command signal is at 50 percent. If the command signal is decreased, the positioner will follow the command until it reaches 5 percent. At 5 percent, the spool will be driven fully open or fully closed, depending on the air action of the valve, in order to provide full actuator saturation and tight shutoff. The positioner will maintain full saturation below 5 percent command signal. As the command increases, the positioner will remain saturated until the command reaches 6 percent (there is a 1 percent hysteresis value added by the positioner). At this point, the stem position will follow the command signal. While in Final Value Cutoff, the Logix 3400IQ LEDs will blink GGGY.

**Q: I have Final Value Cutoff set to 3 percent but the valve will not go below 10 percent.**

A: Is a lower soft stop enabled? The lower soft stop must be less than or equal to zero percent in order for the Final Value Cutoff to become active. If a positive lower soft stop is written, this stop will take priority over the Final Value Cutoff feature. When the lower soft stop is reached, the positioner will blink a GYYR code.

**Q: Will soft stops prevent the valve from going to its fail position?**

A: No.

**Q: What is the difference between a model with Standard diagnostics and a model with Advanced diagnostics?**

A: The model with Advanced diagnostics adds top and bottom actuator pressure sensors. This allows for more diagnostic calculations such as loss of pressure, friction, advanced signatures, and troubleshooting. The pressure sensors, if present, are also used in the positioner control algorithm to enhance valve stability.

**Q: Can I upgrade from a Standard to an Advanced?**

A: Yes. Referencing the IOM, an advanced pressure sensor board assembly can be purchased. Simply replace the pressure sensor plug plate with the advanced pressure sensor board. Perform an actuator pressure calibration.

# 14 How to Order

Table XVII: How to Order

Selection		Code	Example
		3	3
<b>Protocol</b>	FOUNDATION Fieldbus*	4	4
<b>Electronic Hardware Options</b>	Standard Diagnostics*	0	1
	Advanced Diagnostics	1	
<b>Housing &amp; Brand</b>	Aluminum, White Paint (Valtek) *	0	0
	Stainless Steel, No Paint (Valtek)	1	
	Aluminum, Black Paint (Automax)	2	
	Aluminum, Food Grade White Paint (Automax)	3	
	Aluminum, Accord (Balck Paint)	4	
	Aluminum, Accord (Food-Grade White Paint)	5	
	Aluminum - Off Shore Paint	6	
		IQ	IQ
<b>Certifications</b>	Explosionproof Class I, Div 1, Groups B, C, D (FM Only), FM Nonincendive, Class II, Div II Groups E, F, G *	01	1
	General Purpose	14	
<b>Shaft/ Feedback Shaft</b>	DD 316 SSI Shaft (Valtek Standard)*	D6	D6
	NAMUR 316 SSI (VDI/VDE 3845)	N6	
<b>Conduit Connections/ Threaded Connections</b>	½" NPT	E	E
	M20	M	
<b>Action</b>	4-way (Double-Acting)	04	04
	3-way (Single-Acting)	03	
	4-way Vented (Double-Acting)	4V	
	3-way Vented (Single-Acting)	3V	
<b>Temperature</b>	Low -40°C to 85°C (-40°F to 185°F) *	40	40
<b>Gauges</b>	Gauges (Valtek standard)*	0G	0G
	SS with SS internals, psi (bar/kPa)	0S	
	SS with SS internals, psi (kg/cm <sup>2</sup> )	KS	
	SS with brass internals, psi (kg/cm <sup>2</sup> )	KG	
	Stainless Steel	0S	
	No Gauges	0U	
<b>Special Options</b>	None*	00	00
	Remote Mount Feedback (Only available with Certification Option 14)	RM	
	Fail Option Feedback**	SF	

\*Indicates Standard Product Configuration

\*\*Contact factory before specifying this option

## 15 Troubleshooting

Table XVIII: Troubleshooting

Failure	Probable Cause	Corrective Action
No LED is blinking	Voltage of supply source is not high enough	Verify that voltage source can supply at least 9 V
	Current draw incorrect	Verify current draw of device (23 mA) and that of other devices on the loop aren't pulling too much current
Erratic communications	Maximum cable length or cable impedance exceeded	Check cable conduction size, length and capacitance. Refer to Section 6.4, "Cable Requirements"
	Improper grounding	Terminate and ground segment properly.
	Interference with I.S. barrier	Must use FF-compatible I.S. barrier
	Host FB card not configured or connected correctly	Check connections and configurations of card
Unit does not respond to Final Value commands	Unit is in Auto mode	Put in OOS mode
	Error occurred during calibration	Check blink codes on positioner and correct calibration error. Recalibrate
Valve position reading is not what is expected	Positioner tubing backwards	Re-tube the actuator
	Stem position sensor mounting is off 180°	Remount position sensor
	Stroke not calibrated	Perform RE-CAL
	Tight shutoff is active	Verify settings using PC or handheld software
	Customer characterization or soft stops active	Verify customer characterization and soft stops

Failure	Probable Cause	Corrective Action
Position is driven fully open or closed and will not respond to command	Stroke not calibrated	Check DIP switch settings and calibrate valve stroke
	Inner-loop hall sensor not connected	Verify hardware connections
	Wrong air action entered in software	Check ATO (Air-to-open) and ATC (Air-to-close) settings. Recalibrate
	Actuator tubing backward	Verify ATO/ATC actuator tubing
	Driver module Electro-pneumatic converter malfunctioning	Replace driver module
	Control parameter inner-loop offset is too high/low	Adjust inner-loop offset and see if proper control resumes
Sticking or hunting operation of the positioner	Contamination of the driver module	Check air supply for proper filtering and meeting ISA specifications ISA-7.0.01. Check the spool valve for contamination
	Control tuning parameters not correct	Adjust gain settings using local gain switch
	Packing friction high	Enable the stability DIP switch on the local interface and recalibrate. If problem persists, enable pressure control with handheld communicator or SoftTools and recalibrate
	Corroded or dirty spool valve	Disassemble and clean spool valve

\* Final Value Cutoff

**NOTE:** Refer to blink codes for self diagnostics of other errors. See document #VLAIM0046. Refer to Logix 3400/1400 Reference Manual for Fieldbus related troubleshooting.







**United States**  
Flowserve Corporation  
Flow Control  
1350 N. Mt. Springs Parkway  
Springville, UT 84663  
Phone: 801-489-8611  
Fax: 801-489-3719

FCD LGENIM3401-00 Printed in USA.

***To find your local Flowserve representative:***

For more information about Flowserve Corporation, visit [www.flowserve.com](http://www.flowserve.com)  
or call USA 1 800 225 6989

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can (and often does) provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the Installation Operation Maintenance (IOM) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

© 2006 Flowserve Corporation, Irving, Texas, USA.  
Flowserve is a registered trademark of Flowserve Corporation.