



*Logix 800*  
*Digital Positioner*

## *USER INSTRUCTIONS*

*Installation*  
*Operation*  
*Maintenance*



*Experience In Motion*

# Contents

<b>1. Introduction .....</b>	<b>3</b>
Safety instruction .....	3
<b>2. Storage .....</b>	<b>4</b>
General .....	4
Storage indoors .....	4
Storage outdoors or for a longer period .....	4
Storage in a warm place .....	4
<b>3. Design .....</b>	<b>5</b>
<b>4. Variants .....</b>	<b>6</b>
<b>5. Function .....</b>	<b>7</b>
<b>6. Installation .....</b>	<b>8</b>
Tubing .....	8
Air supply requirements .....	8
Mounting .....	9
Connections .....	10
Single action positioner, Direct function .....	11
Double action positioner, Direct function .....	11
Electrical connections .....	12
<b>7. Control .....</b>	<b>14</b>
Menus and pushbuttons .....	14
Other functions .....	14
Menu indicator .....	15
Menus .....	15
Changing parameter values .....	15
Menu system .....	16
First start .....	17
<b>8. Maintenance/service .....</b>	<b>34</b>
Disassembling Logix 800 .....	34
Silencer .....	36
Spindle adapter .....	36
Potentiometer .....	37
Transmitter boards .....	37
Disassembling Logix 800 Ex .....	41
Filter change .....	42
Converting for remote control .....	43
<b>9. Trouble shooting .....</b>	<b>44</b>
<b>10. Technical data .....</b>	<b>45</b>
Signs and certificates .....	50
<b>11. Spare parts .....</b>	<b>56</b>

# 1. Introduction

The Logix 800 is a digital positioner designed primarily for controlling adjustable valves.

The positioner can be used with single or double action actuators with either rotary or linear movement.

The Logix 800 can be equipped with modules for feedback, limit switches, and a pressure gauge block.

The modules can be factory assembled before delivery or fitted later.

The modules for feedback and limit switches can contain the following:

Feedback 4-20 mA and one of the following functions:

- Two mechanical contacts
- Two reed switches
- Two inductive sensors, DIN 19234



## Safety instruction

Read the safety instructions in this manual carefully before using the product. The installation, operation, and maintenance of the product must be done by staff with the necessary training and experience. If any questions arise during installation, contact the supplier/sales office before continuing work.

## Warning

- The valve package moves when in operation and can cause personal injury or damage if handled incorrectly.
- If the input signal fails or is switched off, the valve moves quickly to its end position.
- If the compressed air supply fails or is turned off, fast movements can occur.
- The valve is not controlled by the input signals when in the Out of service mode. It will open/close in the event of a leak.
- If a high value is set for Cut off, fast movements can occur.
- When the valve is controlled in the Manual mode, the valve can move quickly.
- Incorrect settings can cause self-oscillation, which can lead to damage.

## Important

- Always turn off the compressed air supply before removing or disconnecting the air supply connection or the integral filter. Remove or disconnect with care because C- is still under pressure even after the air supply is turned off.
- Always work in an ESD protected area when servicing the PCB's. Make sure the input signal is switched off.
- The air supply must be free from moisture, water, oil and particles.

## Special Conditions for Safe Use

The enclosure of Logix 800I (Intrinsically safe) is made of aluminium and any impact or friction caused by external objects shall be avoided in the application.

## 2. Storage

### General

The Logix 800 positioner is a precision instrument. Therefore it is essential that it is handled and stored in the right way. Always follow the instructions below!

**N.B.** As soon as the positioner is connected and started, internal air leakage will provide protection against corrosion and prevent the ingress of moisture. For this reason, the air supply pressure should always be kept on.

### Storage indoors

Store the positioner in its original packaging. The storage environment must be clean, dry, and cool (15 to 26°C, 59 to 79°F).

### Storage outdoors or for a longer period

If the positioner must be stored outdoors, it is important that all the cover

screws are tightened and that all connections are properly sealed. The unit should be packed with a desiccant (silica gel) in a plastic bag or similar, covered with plastic, and not exposed to sunlight, rain, or snow.

This is also applicable for long-term storage (more than 1 month) and for long transport by sea.

### Storage in a warm place

When the positioner is stored in a warm place with a high relative humidity and is subjected to daily temperature variations, the air inside the unit will expand and contract.

This means that air from outside the unit may be drawn into the positioner. Depending on the temperature variations, relative humidity, and other factors, condensation and corrosion can occur inside the unit, which in turn can give rise to functional disorders or a failure.


# 3. Design

The Logix 800 positioner contains:

- Electronic board with microprocessor, HART modem, Profibus, Foundation Fieldbus, display, etc.
- Valve block
- Positional feedback with potentiometer
- Sealed compartment for electrical connections

The push buttons and display are accessible underneath the aluminium cover, which is sealed with an O-ring.

The figure shows the Logix 800 with the cover removed.



## 4. Variants

### Logix 800 General purpose


The Logix 800 digital positioner has an easy to use user interface with 5 pushbuttons and local graphic LCD display. Communication options include 4-20ma HART, Foundation Fieldbus and Profibus PA. All Logix 800 positioners are available with Feedback, Fail Freeze (Fail in last position and hold when power is lost), 270-degree rotation (for extended travel) and Gauge block.




### Logix 800 Explosion proof

The Logix 800 digital positioner is available in explosion proof enclosure. The explosion proof Logix 800 features the same easy to use interface for local configuration as the **general purpose** version does. Communication with Hart, Foundation Fieldbus and Profibus is possible.

Further features are gauge ports and local graphic LCD display.

ATEX: EEx d IIB + H<sub>2</sub> T6 (Ta +65°C), T5 (Ta +80°C)  II 2GD



### Logix 800 Intrinsically safe

The Logix 800 digital positioner is available in intrinsically safe version for installation in hazardous areas. The intrinsically safe Logix 800 has all the same features and options as the general purpose version, gauge block, local graphic LCD display and feedback option etc. Communication with Hart, Foundation Fieldbus and Profibus is possible.

ATEX: EEx ia IIC T4 Ta=-30...80°C  II 1 GD


CSA, FM Class I Div.1 Grps B,C,D, Class II Div.1 Grps E,F,G, T6, T5.



### Logix 800 remote mounted

This version is suitable for installations in severe applications e.g. vibrations, high or low temperature corrosive environment, or difficult to access areas. A flat or dome style indicator can be fitted on the feedback box installed on the actuator. The maximum recommended distance between the remote unit and the Logix 800 is 5 m (16.4 ft).

# 5. Function



The control signal function and the feedback from the potentiometer position are converted to digital signals that are processed with a PID algorithm in the microprocessor. This provides control signals to the two piezo-valves.

Valves B and E deliver air to the actuator while valves C and F exhaust air from the actuator to atmosphere. Valves B and C are controlled by Piezo-valve 1 and valve A. Valves E and F are controlled by Piezo-Valve 2 and valve D.

Full supply pressure is directed to valves B and E. Air with filtered and reduced pressure is supplied to valves A, C, D and F.

For double acting actuators, connect C+ and C- to the actuator.

For single acting (spring return) actuators connect C+ to the actuator and plug port C-.

## Assume equilibrium

Increasing input signal changes position in piezo-valve 1, causing valve A to close.

Supply pressure is then allowed to open valve B and flow to the actuator via the C+ port. When the actuator reaches its new steady state position piezo-valve 1 closes which causes valves B and C to close shutting off supply air to the actuator.

A decreasing input signal functions in the same manner, except uses piezo-valve 2 and valves D, E and F.

## 6. Installation

### Tubing

Use tubes with a minimum inner diameter 6 mm (1/4").

### Air supply requirements

Max. air supply pressure, see the section Technical Data, Section 10.

The air supply must be free from moisture, water, oil, and particles.

The air must come from a refrigeration dried supply or be treated in such a way that its dew point is at least 10°C (18°F) below the lowest expected ambient temperature.

To ensure a stable and problem-free air supply, we recommend the installation of a filter/pressure regulator <40µ as close to the positioner as possible.

Before the air supply is connected to the positioner, we recommend the hose is opened freely for 2 to 3 minutes to allow any contamination to be blown out. Direct the air jet into a large paper bag to trap any water, oil, or other foreign materials. If this indicates that the air system is contaminated, it should be properly cleaned.



**WARNING!** Do not direct the open air jet towards people or objects because it may cause personal injury or damage.

**Poor quality air supplies are the main source of problems in pneumatic systems.**




# Mounting

**N.B.** If the positioner is installed in a hazardous environment, it must be of a type approved for this purpose.

The Logix 800 positioner, all versions, has an ISO F05 footprint, A. The holes are used to attach the Logix 800 to the mounting bracket B. Please contact PMV or your local distributor representative with actuator specifics for the proper mounting bracket and hardware.

The spindle adapter C can be changed to suit the actuator in question.


Remove the existing adapter using two screwdrivers. Check that the spring ring on




the positioner spindle is undamaged and fit the new adapter.

It is important that the positioner's spindle and the arms, that transfer the actuator movements, are correctly mounted. Any tension between these parts can cause incorrect operation and abnormal wear.

## Assembly examples




*Rotary movement*



*Linear movement*

*Logix 800 Ex positioner  
attached to mounting bracket.*



## Connections

### Air:

- Port S      Supply air, 2-7 bar
- Port C+    Connection to actuator
- Port C-    Connection to actuator  
(only for double action)


### Electrical connection

See page 12, 13.

### Dimensions

- Air connections:  
1/4" NPT alt. G 1/4"
- Electrical connection:  
M20 x 1.5 alt. NPT 1/2"

*Must be plugged when converting to  
single action function.*



C-    S    C+


*For data for air and electrical  
connections, see section  
Technical Data on page 48.*

Loctite 577 or equivalent is recommended  
as a sealant.

## Single action positioner, Direct function

### Actuator with closing spring


When the control signal increases, the pressure C+ to the actuator is **increased**. The valve stem moves upward and rotates the positioner spindle **counter-clockwise**. When the control signal drops to zero, C+ is vented and the valve closes.



## Reverse function

### Actuator with opening spring


When the control signal increases the pressure C+ to the actuator is **increased**. The valve stem moves downward and the positioner spindle rotates **clockwise**. When the control signal drops to zero, C+ is vented and the valve opens.



## Double action positioner, Direct function

### Double action actuator

When the control signal increases, the pressure C+ to the actuator is increased. The valve stem is pressed upward and rotates the positioner spindle counter-clockwise. When the control signal is reduced, the pressure C- to the actuator increases and the valve spindle is pressed downward. If the control signal disappears, the pressure goes to C-, C+ vents, and the valve closes.



### Fail in place (Fail Freeze)

Signal hold at previous position when input signal drops below 3,75 mA.

Drift rate in midrange <0,1% after 30 s and < 2% after 30 min.

## Electrical connections

Terminal block diagram for the Logix 800 and Logix 800 Ex.

### Logix 800

The terminal block (below) for the positioner is accessible when the aluminium cover and inner cover are removed, see Section 8.

### Remote unit

The remote unit shall be connected between terminals 3, 4 and 5 in the Logix 800 and 3, 4 and 5 in the remote unit. Use a shielded cable and ground it in the Logix 800

See Section 10 cdwg D3-70



**Warning!** In a hazardous environment where there is a risk of explosion, electrical connections must comply with the relevant regulations.

only. Max recommended distance between Logix 800 and remote unit: 5 m (16,4 ft).


**Note!** When converting the Logix 800 or Logix 800 Ex to a remote unit, modifications have to be internally with a cable.

When installing Logix 800 Intrinsically safe unit, always consider cdwg D3-70.

### Logix 800, Single board

#### **HART-**

#### **connection**




- 1 Input signal + 4-20 mA ,  
Hart, Profibus, Foundation Fieldbus
- 2 Input signal - 4-20 mA ,  
Hart, Profibus, Foundation Fieldbus
- 3 Switch 1 NO/Remote
- 4 Switch 1 NC/Remote
- 5 Switch 1 COM/Remote
- 6 Switch 2 NO
- 7 Switch 2 NC
- 8 Switch 2 COM
- 9 4-20 mA + Feedback, 13-28 V DC
- 10 4-20 mA - Feedback, 13-28 V DC
- 11 Alarm output +, 8-28 V DC
- 12 Alarm output -, 8-28 V DC

Optional

### Logix 800, Double board

#### **HART-**

#### **connection**



- 1 Input signal + 4-20 mA ,  
Hart, Profibus, Foundation Fieldbus
- 2 Input signal - 4-20 mA ,  
Hart, Profibus, Foundation Fieldbus
- 3 Remote Unit
- 4 Remote Unit
- 5 Remote Unit
- 6 Switch 2 NO
- 7 Switch 2 NC
- 8 Switch 2 COM
- 9 AUX input 4-20 mA +
- 10 AUX input 4-20 mA -
- 11 4-20 mA + Feedback, 13-28 V DC
- 12 4-20 mA - Feedback, 13-28 V DC
- 13 Alarm output +, 8-28 V DC
- 14 Alarm output -, 8-28 V DC

Optional

## Logix 800 Ex

The terminal (below) for the positioner is accessible when the terminal cover is removed, see Section 8.


See Section 10 cdwg D3-70



**Warning!** In a hazardous environment where there is a risk of explosion, electrical connections must comply with the relevant regulations.

### Logix 800 Ex, Single board


#### HART-connection



- 1 Input signal + 4-20 mA ,  
Hart, Profibus, Foundation Fieldbus
- 2 Input signal - 4-20 mA ,  
Hart, Profibus, Foundation Fieldbus
- 3 Remote unit
- 4 Remote unit
- 5 Remote unit
- Optional
- 9 4-20 mA + Feedback, 13-28 V DC
- 10 4-20 mA - Feedback, 13-28 V DC
- 11 Alarm output +, 8-28 V DC
- 12 Alarm output -, 8-28 V DC


### Logix 800 Ex, Double board

#### HART-connection



- 1 Input signal + 4-20 mA ,  
Hart, Profibus, Foundation Fieldbus
- 2 Input signal - 4-20 mA ,  
Hart, Profibus, Foundation Fieldbus
- 3 Remote unit
- 4 Remote unit
- 5 Remote unit
- Optional
- 9 AUX input 4-20 mA +
- 10 AUX input 4-20 mA -
- 11 4-20 mA + Feedback, 13-28 V DC
- 12 4-20 mA - Feedback, 13-28 V DC
- 13 Alarm output +, 8-28 V DC
- 14 Alarm output -, 8-28 V DC

## Connecting a remote unit




# 7. Control

## Menus and pushbuttons

The positioner is controlled using the five pushbuttons and the display, which are accessible when the aluminium cover is removed.

For normal functioning, the display shows the current value. Press the ESC button for two seconds to display the main menu.

Use the  pushbuttons to browse through the main menu and the sub-menus.

The main menu is divided up into a basic menu and a full menu, see page 16.

## Other functions

### ESC

Exit the menu without making any changes (as long as any changes have not been confirmed with OK).

### FUNC


To select function and change parameters.

### OK

To confirm selection or change of parameters.

### MENU INDICATOR

Displays the position of the current menu row in the menu.



## IN SERVICE

The positioner is following the input signal. This is the normal status when the positioner is working.

## OUT OF SERVICE

The positioner is not following the input signal. Critical parameters can be changed.

## MANUAL

The positioner can be adjusted manually using the pushbuttons. See section "Man/Auto", page 21".

## UNPROTECTED

Most of the parameters can be changed when the positioner is in the "Unprotected" position. However, critical parameters are locked when the positioner is in the "In service" position.

## Menu indicator


There are indicators at both sides of the display window and they indicate as follows:

Flashing in position **Out of service**

Flashing in position **Manual**

Displayed in position **Unprotected**

The indicators on the right-hand side show the position in the current menu.



## Menus

To display the menus you can select:


- **Basic menu**, which means you can browse through four different steps
- **Full menu**, which comprises ten steps. Use the Shift Menu to browse through the steps

Full Menu can be locked out using a passcode.

The main menus are shown on the next page and the sub-menus on the subsequent pages.


## Changing parameter values

Change by pressing  until the desired figure is flashing.

Press  to step to the desired figure. Confirm by pressing OK.

A change can be undone by pressing the **ESC** button, which returns you to the previous menu.

# Menu system



The menus are described on the following pages.



## BASIC MENU CALIBRATE



### First start

Calibrate in the basic menu is displayed automatically the first time the power is applied, and can be selected from the basic/main menu at any later time.

A complete auto-calibration takes about 3 minutes and includes end limit calibration, auto-tuning, leak test, and a check on the speed of movement. Start the automatic calibration by selecting **Auto-Cal** and then answer the questions on the display by pressing **OK** or the respective arrow. The menu is described on the next page.

### Calibration error messages

If a fault occurs during calibration, one of the following error messages can be displayed:

#### No movement/press ESC to abort

Typically the result of an air delivery issue to the actuator, or incorrect mounting and/or linkage arrangement. Check for proper supply air to the positioner, pinched tubing, proper actuator sizing, proper linkage and mounting arrangement.

#### Pot uncalibrated/press ESC to abort

The potentiometer has been set to an illegal value. The potentiometer is aligned using the Calibrate - Expert cal - pot Menu. The calibration sequence must be restarted after the fault is corrected.

#### Air leak detected/ESC = abort

##### OK = go on

An air leak has been detected. The calibration sequence should be restarted after the fault is corrected.

### First start, Profibus

Connect the input signal at pos 1 and 2 on the terminal block. See Electrical connections in the manual.

In the SETUP/Devicedata/Profibus: change the address from 126 to any number between 1-125.

Never use the same number with more than one unit. Install values in failsafe mode, for communication when loss of signal.

Calibrate the unit.

GSD files are available at our web-page [www.pmv.nu](http://www.pmv.nu)

### To install the D3\_PROFIBUS.DDL file to Siemens SIMATIC PDM.

1. Move the files to The directory with the DeviceInstall.exe. There should be one existing from Siemens that is included in PDM
2. Run the Program DeviceInstall.exe

Parameter	Description	BYTE
SP	Setpoint	The SP has 5 bytes, 4 bytes for the float value and one status byte that has to be 128 or over (80 in hex) for the D3 to accept it. Use 128 means GOOD and everything should work fine. 4+1=5
READBACK	Position	The READBACK has 5 bytes, 4 bytes for the float value and one status byte. 4+1=5
POS_D	Digital position	Gets a position in digital form 0 = Not initialized 1 = Opened 2 = Closed 3 = Intermediate 2
CHECKBACK		Detailed information of the device, bit wise coded, more than one message possible at ones. 3
RCAS_IN	Remote Cascade	The RCAS_IN has 5 bytes, 4 bytes for the float value and one status byte. 4+1=5
RCAS_OUT	Remote Cascade	The RCAS_OUT has 5 bytes, 4 bytes for the float value and one status byte. 4+1=5
Status Byte		

MSB	LSB meaning	D3 use
0 0 0 0 1 0 x x	not connected	
0 0 0 0 1 1 x x	device failure	PROFibus PA module failure
0 0 0 1 0 0 x x	sensor failure	No sensor value
0 0 0 1 1 1 x x	out of service	AI Function Block in O/S mode
1 0 0 0 0 0 x x	Good -	Non cascade measured value OK All Alarm values used
1 0 0 0 0 0 0 0	ok	
1 0 0 0 1 0 0 1	below low limit Lo	Advisory alarm
1 0 0 0 1 0 1 1	Above high limit Hi	Advisory alarm
1 0 0 0 1 1 0 1	Lo-Lo	Critical alarm
1 0 0 0 1 1 1 1	Hi-Hi	Critical alarm

Example SP = 43.7% and 50%  
Float    Hex        Status  
43.7    42 2E CC CD    80  
50.0    42 48 00 00    80

## (FF) Fieldbus Foundation function blocks

Function blocks are sets of data sorted by function and use. They can be connected to each other to solve a control process, or to a controlling DCS. To get a good introduction and understanding of FF look at [www.fieldbus.org](http://www.fieldbus.org) and download the “Technical Overview” from the About FF pages.

### (TB) Transducer Block

The TB contains unit specific data. Most of the parameters are the same as parameters found on the display. The data and the order of data varies between different products.

The AO-block setpoint (SP) and process value (PV) parameters are transceived to the TB through a channel.

The TB has to be in AUTO for the AO-block to be in AUTO.

The positioner has to be in menu-auto mode and in service to be controlled from the fieldbus.

If the positioner is placed in menu-manual mode then the transducer block will be forced to (LO) local override. In this way a person in the field will be able to control the positioner from the keypad, without collision with a control loop.

### (RB) Resource Block

The RB is a set of parameters that looks the same for all units and products. The values of the RB define unit information that concerns the Fieldbus Protocol such as

MANUFAC\_ID which informs the unique manufacturer id. For Flowserve it is 0x464C53.

The RB has to be in AUTO for the AO-block to be in AUTO.

### (AO) Analogue Output Block

The AO follows Fieldbus Foundation’s standard on content and action. It is used for transferring (SP) setpoints from the bus to the positioner.

CAS\_IN (cascade input) and RCAS\_IN (remote cascade input) are selected as inputs to the AO block depending on the MODE\_BLK parameter. The selected input will be relayed to the SP parameter of the AO block. BKCAL\_OUT (back calculated output) is a calculated output that can be sent back to a controlling object so that control bumps can be avoided. Usually the BKCAL\_OUT is set to be the (PV) process value of the AO-block, i.e. the actual measured position of the valve.

OUT is the primary calculated output of the AO block. During a limited action (ramping) of the AO block the RCAS\_OUT parameter will supply the final setpoint and the OUT parameter will be the limited output.


The transducer block is connected through a channel to the AO block. Through this channel the OUT value and SP are transceived.

In order to set the AO block to AUTO, the TB and the RB have to be in AUTO. Further the AO block has to be scheduled. Using National Instruments Configurator; scheduling can be done by adding the unit to a project and then click on the “upload to device”-icon.


To write a setpoint value by hand, add Man to MODE->Permitted parameter, and then choose MODE->Target to Man. Make sure that the unit is scheduled.

### Example

A typical FF block loop control might look like the following:



Where the positioner is represented by the AO-block.



**BASIC MENU  
CALIBRATE**




The contents of the menu are shown on the next page. The various menu texts are described below.

**Auto-Cal**

**Start tune**

Auto-tuning and calibration of end positions

Starts the tuning. Questions/commands are displayed during calibration. Select the type of movement, function, etc. with  and confirm with **OK** as shown in the chart on the next page.

**Lose prev value? OK?**

A warning that the value set previously will be lost (not during the first auto-tuning).

**Actuator? rotating**

Select for rotating actuator.

**Actuator? linear**

Select for linear actuator.

**Actuator single act**

Select for single act.

**Actuator double act**

Select for double act.

**Direction? direct**

Select for direct function.

**Direction? reverse**

Select for reverse function.

**In service? Press OK**

Calibration finished. Press OK to start positioner functioning. (If ESC is pressed, the positioner assumes the "Out of service" position but the calibration is retained).

**TravelCal**

**Start cal**

Calibration of end positions

Start end position calibration.

**Lose prev value? OK?**

A warning that the previously set value will be lost. Confirm with OK.

The calibration sequence starts.

**In service? Press OK**

Calibration finished. Press OK to start positioner functioning. (If ESC is pressed, the positioner assumes the "Out of service" position but the calibration is retained).

**Perform**

**Normal**

Setting gain

100% gain

**Perform 50%, 25%,**

**12%, L, M, S**

Possibility to select a lower gain in steps.

**L, M, S**

Preset values for L, M, S actuators

**Factory set**

Resets all set values and enters Factory Mode. **Should only be used by authorized staff.**

**Note.** Original P. I. D. will always be shown in display

## ExpertCal

**Set point LO:** Use the calibrator set to 4 mA (or set another value on the display). Press OK.

**Set point HI:** Use a calibrator of 20 mA (or set another value on the display). Press OK.

**Pressure LO:** Use a supply of 2 bar (30 psi) (or set another value on the display). Press OK.  
Pressure read out only possible on Logix 800 with built in pressure sensor.

**Pressure HI:** Use a supply of 7 bar (105 psi) (or set another value on the display). Press OK.  
Pressure read out only possible on Logix 800 with built in pressure sensor.

**Temp:** Calibrate using a known temperature.

**Aux input LO:** Use the calibrator and a power supply of 4 mA (or set another value on the display). Press OK.

**Aux input HI:** Use a supply of 20 mA (or set another value on the display). Press OK.

**Pot:** Potentiometer setting, if its position relative to the gear segment has been changed. See Section 8.


**Full reset:** Resets all the set values.

Only Double board

The menu contents are shown in the figures on the right and the texts are described below:



Current values can be read using the Read Menu and some values can be reset.





The Man/Auto menu is used to change between manual and automatic modes.

The menu contents are shown in the figures on the right and the various texts are described below:





**AUT, OK = MAN**

Positioner in automatic mode

**MAN, OK = AUT**


Positioner in manual mode



When changing between **MAN** and **AUT** mode, the **OK** button must be pressed for 3 seconds.

In the **MAN** mode, the value of POS can be changed using  . The push-buttons increase/decrease the value in steps. The value can also be changed in the same way as for the other parameter values, as described on page 15.

### Other functions

C+ can be fully opened by pressing  and then immediately OK simultaneously.

C- can be fully opened by pressing  and OK simultaneously.


C+ and C- can be fully opened for blowing clean by pressing   and OK simultaneously.




The Shift Menu is used to choose between the basic menu and the full menu.

The menu contents are shown in the figures on the right and the various texts are described below:

- No Full menu selected.
- Yes Basic menu selected.




Full Menu can be locked with a passcode, see Setup menu.



The Write Protect menu is used to protect all essential settings.


The menu contents are shown in the figures on the right and the various texts are described below:

- No Entered values are not write protected. "Unprotected" is displayed in the lower left-hand corner.
- Yes Entered values are write protected. Passcod needed for change to No (Applicable when a passcode has been set up in SETUP menu).



When changing between Yes and No mode, the OK button must be pressed for 3 seconds.






The Status Menu is used to select whether or not the positioner is in service.


The menu contents are shown in the figures on the right and the various texts are described below:

**o o service** Not in service. Flashing indicator in upper left-hand corner of display.

**in service** Positioner in service. Critical parameters cannot be changed.



When changing between **In service** and **Out of service**, the **OK** button must be pressed for 3 seconds.



The Setup Menu is used for various settings.

The menu contents are shown in the chart on the next page and the various texts are described below:

<u>Actuator</u>	<u>Type of actuator</u>	<u>Size of actuator</u>	<u>Time out</u>
<b>Rotating</b>	Rotating actuator.	Small	10 s
<b>Linear</b>	Linear actuator.	Medium	25 s
		Large	60 s
		Texas	180 s


<b>Lever</b>	<u>Only for linear actuator.</u>
<b>Lever stroke</b>	Stroke length to achieve correct display.
<b>Level cal</b>	Calibration of positions to achieve correct display.

<u>Direction</u>	
<b>Direct</b>	Direct function (signal increase opens). Indicator/spindle rotates counter-clockwise.
<b>Reverse</b>	Reverse function.

**Character**      Curves that show position as a function of input signal.

<b>Linear</b>	See diagram.
<b>Equal %</b>	
<b>Quick open</b>	
<b>Sqr root</b>	
<b>Custom</b>	Create own curve.

<u>Cust chr</u>	
<b># of point</b>	Specify number of points (3, 5, 9, 17, or 33)
<b>Cust curve</b>	Enter values on X and Y axes.



<b>Curr range</b>	
<b>0%=4.0 mA</b>	
<b>100%=20.0 mA</b>	Possibility of selecting which input signal values will correspond to 0% and 100% movement respectively. Examples of settings: 4 mA = 0%, 12 mA = 100%, 12 mA = 0%, 20 mA = 100%.

<b><u>TRVL range</u></b> <b>0%=0.0%</b>	<u>Setting end positions</u> Select Out of Service. Set percentage value for desired end position (e.g. 3%).		
<b>Set 0%</b>	Select In Service. Connect calibrator. Move forward to desired end position (0%) and press OK.	<b>Start menu</b>	The display reverts to this value 10 minutes after any change is made. Start in Basic menu or Full menu.
<b>100%=100.0%</b>	Select Out of Service. Set percentage value for desired end position (e.g. 97%).	<b>Contrast</b>	Adjust display contrast (Only Double board).
<b>Set 100%</b>	Select In Service. Connect calibrator. Move forward to desired end position (100%) and press OK.	<b>Orient</b>	Orientation of text on display.
		<b>Par mode</b>	Display of control parameters such as P, I, D or K, Ti, Td.
<b><u>Trvl ctrl</u></b>	<u>Behaviour at set end position</u>	<b><u>Devicedata</u></b>	
<b>Set low</b>	Choose between Free (go to mechanical stop), Limit (stop at set end position), and Cut off (go directly to mechanical stop at set end position). Similar to Set low.	<b>HW rew</b>	General parameters.
<b>Set high Values</b>	Select position for Cut off and Limit at the respective end positions.	<b>SW rew</b>	
		<b>Capability</b>	
<b><u>Passcodes</u></b>	<u>Setting passcodes for various functions</u>	<b>HART</b>	Menu with HART parameters. Only amendable with HART communicator. It is possible to read from display.
<b>Full menu</b>	Passcode for access to full menu.	<b>Profibus</b>	
<b>Write prot</b>	Passcode for removing write protect.	<b>Status</b>	Indicates present status
<b>Expert</b>	Passcode for access to Expert menu (TUNING).	<b>Device ID</b>	Serial number
<b>Fact set</b>	Passcode to return to default values applicable when positioner was delivered.	<b>Address</b>	1-126
		<b>Tag</b>	Allotted ID
		<b>Descriptor</b>	ID description
		<b>Date</b>	N/A
		<b>Failsafe</b>	Value = preset pos Time = Set time +10sec= time before movement Valve act = failsafe (preset pos) or lastvalue (present pos) Alarm out= On/Off
		<b>Foundation Fieldbus</b>	
		<b>Device ID</b>	Serial number
		<b>Nod address</b>	Address on the bus provided by the DCS system
		<b>TAG-PD_TAG</b>	Name provided by the DCS system
		<b>Descriptor</b>	Logix 800 positioner
		<b>Date</b>	N/A (not applicable)
		<b>Sim jumper</b>	Simulate jumper, FF simulation functionality activated = ON
<b><u>Appearance</u></b>	<u>On display</u>		
<b>Language</b>	Select menu language.		
<b>Units</b>	Select units.		
<b>Def. Display</b>	Select value(s) to be displayed during service.		

Numbers between 0000 and 9999 can be used as passcodes. 0 = no passcode required.



The menu contents are shown in the chart on the next page and the various texts are described below:

<b><u>Close time</u></b>	<u>Minimum time (Min 0.005) from fully open to closed.</u>
<b><u>Open time</u></b>	<u>Minimum time (Min 0.05) from closed to fully open.</u>
<b><u>Deadband</u></b>	<u>Setting deadband. Min. 0.2%.</u>
<b><u>Expert</u></b>	<u>Advanced settings.</u>
<b>Control</b>	See explanations below.
<b>Togglestep</b>	Test tool for checking functions. Overlays a square wave on the set value.
<b>Self test</b>	Test of processor, potentiometer, etc.
<b>Leakage</b>	Air leakage detected can be either connections, positioner tubing or actuator.
<b>Undo</b>	You can read last 20 changes.

### **P,I,D and K,Ti,Td parameters**

If one of the gains is changed, the corresponding value in the other gain set is changed accordingly.

### **Min Pulse**

The minimum pulse lengths (the“minpulses”) are displayed in the menu, and can be changed.

### **Spring adjust**


The spring adjust function compensates the airflow linearly with the actuator C+ chamber volume (for a constant position error), so that low volumes get less flow. This is needed for linear single-acting actuators, where a low C+ volume means that the actuator spring is extended, its force is reduced, and less flow is needed for stable position changes.

FULL MENU  
ALARMS



The menu contents are shown in the chart on the next page and the various texts are described below:

<b><u>Deviation</u></b>	<u>Alarm generated when deviation occurs</u>
<b>On/Off</b>	Alarm on/off.
<b>Distance</b>	Allowed distance before alarm is generated.
<b>Time</b>	Total deviation time before alarm is generated.
<b>Alarm out</b>	Select ON/OFF offers output on terminals 13 and 14.
<b>Valve act</b>	Behaviour of valve when alarm is generated.
<b><u>Limit 1</u></b>	<u>Alarm above/below a certain level.</u>
<b>On/Off</b>	Alarm on/off.
<b>Minipos</b>	Setting of desired min. position.
<b>Maxpos</b>	Setting of desired max. position.
<b>Hysteresis</b>	Desired hysteresis.
<b>Alarm on</b>	Select ON/OFF offers output on terminals 11 and 12 (Single Board) or 13 and 14 (Double Board).
<b>Valve act</b>	Behaviour of valve when alarm is generated.
<b><u>Limit 2</u></b>	<u>See Limit 1.</u>



Only Double board	<b><u>Pos=aux</u></b>	<u>External potentiometer</u>	
	<b>On/Off</b>	Function on/off.	
	<b>Max diff</b>	Max. allowed deviation between internal and external potentiometer.	
	<b>Alarm out</b>	Select ON/OFF offers output on terminals 13 and 14.	
	<b>Valve act</b>	Behaviour of valve when alarm is generated.	
	<b><u>Aux input</u></b>	<u>External input signal 4-20 mA.</u>	
	<b>On/Off</b>	Alarm on/off.	
	<b>Minipos</b>	Setting of desired min. position.	Function similar to Limit 1 and 2. See chart on previous page.
	<b>Maxpos</b>	Setting of desired max. position.	
	<b>Hysteresis</b>	Desired hysteresis.	
	<b>Valve act</b>	Behaviour of valve when alarm is generated.	
	<b><u>Temp</u></b>	<b><u>Alarm based on temperature</u></b>	
	<b>On/Off</b>	Temperature alarm on/off.	
	<b>Low temp</b>	Temperature setting.	
	<b>High temp</b>	Temperature setting.	
	<b>Hysteresis</b>	Allowed hysteresis.	
	<b>Alarm out</b>	Select ON/OFF offers output on terminals 13 and 14.	
	<b>Valve act</b>	Behaviour of valve when alarm is generated.	


### Valve act

<b>No action</b>	Alarm generated only. Operations not affected.
<b>Goto open</b>	C+ gives full pressure and valve moves to fully open position. Positioner changes to position Manual.
<b>Goto close</b>	C- gives full pressure and valve moves to fully closed position. Positioner changes to position Manual.
<b>Manual</b>	Valve stays in unchanged position. Positioner moves to position Manual.



The menu contents are shown in the chart below.

The default values that were set on delivery can be reset using the Fact Set menu. Values from calibration and from other settings will then be lost.



Single Board

READ					pos	
MAN/AUTO	AUT,OK=MAN	MAN,OK=AUT	normal	50%	set&pos	
CALIBRATE	AutoCal		25%	Pos Graph	n cycles	
	TravelCal		12%	temp	acc travel	
	Perform			statistics	mean dev	
	Expert cal			alarms	runtime	
SHIFT MENU	Basic menu	setpoint	preset L		# of reset	
	Full menu	transm.	preset M		extr temp	
		pot	preset S		histogram	
PROTECTION	no		factory se		reset stat	
	yes	Enter code				
STATUS	O O SERVICE					
	IN SERVICE		Rotating			
	type	Linear	single act		small	
SETUP	function		double act		medium	
	size				large	
	Actuator				Texas-size	
	Lever (*)	Stroke				
	Direction	Lever cal	direct			
	Character					
	Cust chr	#of points	X0=		linear	
		Cust curve	Y0=		equal %	
	Curr range	0% =		0% =	quick open	
		100%=		Set 0%	custom	
	Trvl range			100%=	sqr root	
				Set 100%		
	Trvl ctrl	Set low	free	Cutoff Low		
		Set high	cutoff	Cutoff Hi		
		Values	limited	Limit Low		
	Transm.			Limit Hi	Position	
				Value	Set Point	
				Trans. Card		
	Passcodes				D3-38	
					D3-81	
	Appearance	Language	English		full menu	
			Svenska		protection	
		Deutsch	percent	expert		
		français	mA	fact set		
		Italiano	mm			
		español	cm			
Units		Setpoint	inch	percent		
		Position	degrees	mm		
		Temp		cm		
				inch	Grad C	
				degrees	Grad F	
					Kelvin	
	Def. Displ			pos		
	Start menu			set&pos		
	StartLogo			set&dev		
	Orient.	normal	On/off	last value	menu	
		flipped		basic		
				full		
Devicedata				HW rev	Message	
TUNING	Close time	Control	P.I.D		Tag	
	Open time	Toggle/step	K,Ti,Td		Descriptor	
	Deadband	Self test	Min Pulse	run time	Date	
	Expert	leakage	Shoot/Prote	cycle time	Device ID	
		Undo	Spring Adj	size	Poll adr	
			Stroketime	start	Assemblyno	
				abort step	univ cmd	
					spec cmd	
					Burst	
					On/off	
					Burst Mode	
					4 Dynamic	
ALARMS	Deviation					
	Limit 1	On/off	On/off			
	Limit 2	Min pos	Distance			
		Max pos	Time			
		Hysteresis	Alarm out			
		Alarm out	Valve act			
		Valve act				
			On/off			
			Low temp			
			High temp			
Temp		Hysteresis				
		Alarm out				
		Valve act				
			Valve act	no action		
				goto open		
				goto close		
				manual		
FACT SET	no					
	yes					



[illegible]

# 8. Maintenance/service

When carrying out service, replacing a circuit board, etc., it may be necessary to remove and refit various parts of the positioner. This is described on the following pages.

**Read the Safety Instructions on page 3 before starting work on the positioner.**

Cleanliness is essential when working with the positioner. Contamination in the air ducts will infallible lead to operational disturbances. Do not disassemble the unit more than that described here.

**Do not take the valve block apart because its function will be impaired.**

**When working with the Logix 800 positioner, the work place must be equipped with ESD protection before the work is started.**



**Always turn off the air and electrical supplies before starting any work.**




**When upgrading electronically parts inside a Logix positioner approved for installation in Hazardous locations special procedures apply, permission from PMV/Flowserve is required prior to the start of work.**

**Please contact a Flowserve office for information regarding proper procedures.**  
[www.pmv.nu](http://www.pmv.nu) or [infopmv@flowserve.com](mailto:infopmv@flowserve.com)


## Disassembling Logix 800

### Removing cover and inner cover

- Unscrew the screws A and remove the cover.



- Pull off the arrow pointer, B.
- Unscrew the screws C, pull the inner cover slightly in the direction of the arrow, and remove the cover.




## Circuit boards (pcb)




**Disconnect or switch off the electric power supply before starting any work.**


- Lift off the display pcb.



- Unscrew the spacers E, release the cable connections F and G, and lift up the processor pcb.



- Remove the terminal board by unscrewing the spacers H.




## Valve block



**Turn off the air and electric power supply before starting any work.**


- Release the connector F from the processor pcb.
- Remove the four screws I.



- Lift out the valve block


### **N.B. Do not disassemble the valve block**

- When installing the valve block — torque the four screws to 1,4 Nm and seal with Loctite 222.



## Silencer

A silencer, L (option) can be mounted under the plate M on the Logix 800. Contact PMV.



## Spindle adapter

The spindle adapter can be changed to suit the actuator in question, see page 9.


## Potentiometer

### 90° and 270° spring loaded potentiometer

The spring-loaded potentiometer **K** can be removed from the gearwheel for calibration or replacement.

If the potentiometer is replaced or the setting is changed, it must be calibrated.

- Select the menu Calibrate - Expert - Cal pot. The display shows Set gear (1).
- Turn the spindle shaft (2) cw to end position and press OK. Turn ccw to the end and press OK.
- Unmesh the potentiometer (3) and turn it according to display until OK is shown. Press OK.




## Transmitter boards

The equipment for transmitter feedback consists of a circuit board A, cam assembly B and screws.

The circuit board exists in four:

- with mechanical switches, SPDT
- with namur sensors, DIN 19234
- with proximity switches
- with feedback transmitter only



## Transmitter board installation



**Caution!** Turn off the power and air supply before starting the installation.

**Important for Logix 800 units with hazardous approvals:**

**Maintenance and repairs only to be made by authorized staff.**





- Remove the cover, indicator and inner cover according to the description on page 37.

- Check that both spacers **C** are installed.


- Carefully mount the circuit board in its position. The pins **D** should fit in the connector and the positioner motherboard. Make sure that the feed back PC board is properly connected.

- Secure the circuit board with the enclosed screws **E**.


- Install the cam assembly **B** on the shaft and push it down to its position. If the board has microswitches, be careful not to damage the levers.



- Tighten the screws **F**, on the cam assembly. Do not tighten the screws to hard. The cams should be able to move in relation to each other.




- Install the inner cover with the two screws, **G**.




- Connect the wiring for the transmitter feedback on the terminal block, according to the drawing on next page.

- Adjust the position where the switches/sensors should be affected, by turning the cams with a screwdriver.



- Tighten the cam assembly screws **F** when the cams are correctly adjusted.

- Install the indicator and cover. To calibrate the feedback transmitter, see drawing on next page.








## Disassembling Logix 800 Ex

- Loosen the screws **A** and **B** and remove the caps **C** och **D**.

- Remove the inner display cover **E** by loosening the four screws **F**.

- Carefully remove the display board and loosen the connections **H** and **I**.




- Release the wide cable from the connector **J** on the terminal board.

- Loosen the three screws **K**.

- Remove the circuit board package **L**, consisting of terminal and processor board.

- Remove the four screws **M** and lift the block **N**.




## Filter change, Logix 800 and Logix 800 Ex



Turn off the compressed air supply before starting any work. Otherwise the filter can be uncontrollably blown out of the positioner by the air pressure, which can be dangerous.

- Remove the filter cap using a coin of suitable size.

**Note!** Do not use a screwdriver. The filter cap might crack and cause air leakage.




## Converting for remote control



**Disconnect or switch off the electric power supply before starting any work.**


- Remove cover and inner cover, see page 37.

- Lift off the display pcb, **D**.



- Disconnect and secure the pot cable.

- Install transmitter board D3-AS38T, **F**.





- Install the enclosed wire between **G** and **O** on the transmitter board.

- Connect the wiring between terminals 3, 4, 5 in the Logix 800 unit and 3, 4, 5 in the remote unit.

Use a shielded wire and ground it in the Logix 800 unit only.

Avoid longer distance than 5 m between Logix 800 unit and remote unit.



## 9. Trouble shooting

Fault symptom	Action
Change in input signal to positioner does not affect actuator position.	<ul style="list-style-type: none"> <li>• Check air supply pressure, air cleanliness, and connection between positioner and actuator.</li> <li>• Out of service.</li> <li>• Check input signal to positioner.</li> <li>• Check mounting and connections of positioner and actuator.</li> </ul>
Change in input signal to positioner makes actuator move to its end position.	<ul style="list-style-type: none"> <li>• Check input signal.</li> <li>• Check mounting and connections of positioner and actuator.</li> </ul>
Inaccurate regulation.	<ul style="list-style-type: none"> <li>• Implement auto-tuning. Check for any leaks.</li> <li>• Uneven air supply pressure.</li> <li>• Uneven input signal.</li> <li>• Wrong size of actuator being used.</li> <li>• High friction in actuator/valve package.</li> <li>• Excess play in actuator/valve package.</li> <li>• Excess play in mounting of positioner on actuator.</li> <li>• Dirty/humid supply air.</li> </ul>
Slow movements, unstable regulation.	<ul style="list-style-type: none"> <li>• Implement auto-tuning.</li> <li>• Increase the deadband (Tuning menu).</li> <li>• Adjust Performance (Calibrate menu).</li> </ul>

# 10. Technical data

Rotation angle	min. 30° max 100°, option 270°
Stroke	5—130 mm (0.2" to 5.1")
Input signal	4—20 mA
Air supply	2—7 bar (30—105 psi) Free from oil, water and moisture. Filtered to min. 30 micron
Air delivery	350 nl/min (13.8 scfm)
Air consumption	<0.3 nl/min (0.01 scfm)
Air connections	1/4" G or NPT
Cable entry	3 x M20 or 1/2" NPT
Electrical connections	Screw terminals 2.5 mm <sup>2</sup> /AWG14
Linearity	<1%
Repeatability	<0.5%
Hysteresis	<0.4%
Dead band	0.2—10% adjustable
Display	Graphic, view area 15 x 41mm (0.6 x 1.6")
UI	5 push buttons
Processor	16 bit, M 16C
CE directives	93/68EEC, 89/336/EEC, 92/31/EEC
EMC	EN 50 081-2, EN 50 082-2
Voltage drop, Double board	<10.1 V => resistance 505 Ω
Voltage drop, Single board without HART	< 8.0 V => resistance 400 Ω
Voltage drop, Single board with HART	< 9.4 V => resistance 470 Ω
Vibrations	<1% up to 10 g at frequency 10 — 500 Hz
Enclosure	IP66/NEMA 4X
Material	Die-cast aluminium, A2/A4 fasteners
Surface treatment	Powder epoxy
Temperature range	–30 to +80°C (–22 to 176° F)
Weight	Logix 800X, 1.4 kg (3 lbs). Logix 800E, 3 kg (6.6 lbs)
Alarm output	Transistor Ri 1 KΩ
Alarm Supply Voltage	8—28 V DC
Mounting position	Any

## Mechanical switches

Type	SPDT
Size	Sub Sub miniature
Rating	3 A/125 V AC 2 A/30 V DC

## Namur sensors (N32-V3-N)

Type	Proximity DIN 19234 NAMUR
Load current	$1 \text{ mA} \leq I \leq 3 \text{ mA}$
Voltage range	5 - 25 V DC
Hysteresis	0.2 %
Temp	-20°C to 85°C (-4°F to 185°F)

## Proximity switches




Type	SPDT
Rating	5 W/250 mA/30 V DC/125 V AC
Operating time	0.7 ms
Breakdown voltage	200 V DC
Contact resistance	0.1 $\Omega$
Mechanical/electrical life	>50 x 10 <sup>6</sup> operations




## Slot Namur switches (S32-S1N, S32-SN, S32-N)

Type	Proximity DIN EN 60947-5-6
Load current	$1 \text{ mA} \leq I \leq 3 \text{ mA}$
Voltage	8 V DC
Hysteresis	0.2 %
Temp	-25°C to 85°C (-13°F to 185°F)






## 4 - 20 mA transmitter

Supply	9 - 28 V DC
Output	4 - 20 mA
Resolution	0.1 %
Linearity full span	+/-0.5 %
Output current limit	30 mA DC
Load impedance	800 $\Omega$ @ 24 V DC









## Signs and certificates

### **D3E:**

**D3E EXPLOSION PROOF DIGITAL VALVE POSITIONER**

Class I Div.1 Grps B,C&D, Class II Div.1

Grps E,F&GT6(Ta +149 F) T5(Ta +176 F)

NEMA Type 4X/ IP66



EEx d IIB + H T6 (Ta +65 C) T5 (Ta +80 C) NEMKO 03 ATEX 111



II 2 GD



0470

Electrical Rating: max 28V DC, max 24mA, max 0,67 W

Do not open while energized! Seal within 50 mm of the enclosure.

Serial number, production year, software revision

FLowsERVE, SWEDEN; PALMSTIERNA INTERNATIONAL, SOLNA





# Certificate of Compliance

Certificate: 1278854  
 Project: 1278854  
 Issued to: Palmsternas Instrument AB  
 Korta Gatån 9  
 Solna, 171 54  
 SWEDEN  
 Attention: Mr. Mats Ragnarsson

Master Contract: 176847  
 Date Issued: February 7, 2002

The products listed below are eligible to bear the CSA Mark shown



Issued by: R. Wildish  
 Authorized by:  R. Wildish  
 Operation Manager

## PRODUCTS

CLASS 2258 02 - PROCESS CONTROL EQUIPMENT - For Hazardous Locations  
 Class I, Div. 1, Groups C and D; Class II, Div. 1, Groups E, F and G; Class III, Div. 1; Encl. Type 4X;  
 Model D3E xUx23PVBZAX Electronic-Pneumatic Valve Positioner; input rated 28 Vdc, 24 mA max. Temp. Code T6 @ Max Ambient 65 Deg C; Temp. Code TS @ Max Ambient 81 Deg C.  
 Note: the x's in the D3E model code denote minor mechanical and electrical variations.

FM APPROVALS  
 PROJECT ID: 301533  
 D3E DIGITAL VALVE POSITIONER

From  
 Palmsternas Instrument AB  
 Korta Gatån 9  
 S-17154 Solna, Sweden

### I INTRODUCTION

- 1.1

Palmsternas Instrument AB (manufacturer) requested continued FM Approval of their modified Digital Valve Positioner, Series D3E as explosionproof for Class I, Division 1, Groups B, C & D, To Ta = 65°C / T1 Ta = 80°C; dust-ignitionproof for Class II, Division 1, Groups E, F & G, T6 Ta = 65°C / T5 Ta = 80°C; indoor and outdoor (Type 4X) hazardous (classified) locations. The D3E Digital Valve Positioner is designed to control modulating valves.
- 1.2

This Report may be freely reproduced only in its entirety and without modification.
- 1.3

Standards: Approval of the D3E Digital Valve Positioner is based on the applicable requirements of the following standards.

Title	Class Number	Date
Electrical Equipment for Use in Hazardous (Classified) Locations General Requirements	FM 3600	1998
Explosionproof Electrical Equipment for Hazardous (Classified) Locations	FM 3615	1989
Electrical and Electronic Test, Measuring and Process Control Equipment	3810 Including Supplement #1	March 1989 July 1995
Enclosures for Electrical Equipment	ANSI/NEMA 250	1991

- 1.4

As described in this report, the design and construction of the D3E Digital Valve Positioner provides for the required degree of protection against electrical shock, fire, and injury for hazardous (classified) locations.
- 1.5

**Listing:** The revised product listing will appear in the FM Approval Electrical Equipment Approval Guide, Chapter 2 as follows: (Additions are indicated by underline.)  
**D3E**Ux23PVBZAX, **Digital Valve Positioner**,  
 XP/II/BCD/T6 Ta = 65°C/T5 Ta = 80°C; DIP/III/IEFG/T6 Ta = 65°C/T5 Ta = 80°C; Type 4X  
 a = G or N. Air pipe connection thread type.  
 c = S, D, C or R. Function.  
 ign = A, B, C, D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S, T, U, V, W, X, Y, Z, AA, AB or YZCA. Cover and Indicator.  
 j = 4, 5, 1 or F. Input signal protocol.
- 1.6

This report supplements FM Approvals Report ID: 3012463 which describes the original version of this product.



Page 1 of 2

**(1) EC-TYPE EXAMINATION CERTIFICATE**

(2) Equipment or Protective System Intended for use in Potentially explosive atmospheres  
Directive 94/9/EC

- (3) EC-Type Examination Certificate Number: Nemko 03ATEX1111
- (4) Equipment or Protective System: Digital Valve Positioner  
PMV Palmsjöströms Instrument AB
- (5) Applicant/ Manufacturer: Korta gatan 9  
S-17154 Solna  
Sweden
- (6) Address:
- (7) This equipment or protective system and any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to.
- (8) Nemko AS, notified body number 4470 in accordance with Article 9 of Council Directive 94/9/EC of 23 March 1994, certifies that this equipment or protective system has been found to comply with the Essential Health and Safety Requirements of the Directive and that it is suitable for use in potentially explosive atmospheres classified for use in potentially explosive atmospheres given in Annex II to the Directive.
- The examination and test results are recorded in confidential report no. 200309114
- (9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:  
CENELEC EN 50014: 1997 + A1: 1999 + A2: 1999  
CENELEC EN 50018: 2000
- (10) If the sign "X" is placed after the certificate number, it indicates that the equipment or protective system is subject to special conditions for safe use specified in the schedule to this certificate.
- (11) This EC-TYPE EXAMINATION CERTIFICATE relates only to the design, examination and tests of the specified equipment or protective system in accordance to the Directive 94/9/EC.  
Further requirements of the Directive apply to the manufacturing process and supply of this equipment or protective system. These are not covered by this certificate.
- (12) The marking of the equipment or protective system shall include the following:

II 2 G EEx d IIB + H2 T6(Ta:65°C) T5(Ta:80°C)

Oslo, 2003-04-23

*R. Rydholm*  
Rolf Rydholm  
Certification Department

This certificate may only be reproduced in its entirety and without any change, schedule included.

Printed address: Oslo, Norway  
Office address: 0375 OSLO  
Telephone: +47 22 96 61 30  
Fax: +47 22 96 61 50  
Enterprise number: NO 174406532



Page 2 of 2

Nemko 03ATEX1111

Date: 2003-04-23

**(13) Schedule**

**[14] EC-TYPE EXAMINATION CERTIFICATE No Nemko 03ATEX1111**

- (15) Description of Equipment or Protective System  
The PMV DVE is a digital positioner designed primarily to control modulating valves. The positioner can be used with linear actuators and rotary actuators. The positioner is supplied with 24VDC. The DVE is a compact unit comprising an electronic board with microprocessor, hart modem, display etc. a valve block, a positional feedback with potentiometer and a compartment for electrical connections.  
The pushbuttons and display are accessible from underneath the threaded lid cover.  
The whole assembly is contained in a flameproof aluminum enclosure with two threaded lids and two threaded openings for cable glands/conduits. Flame arresters are integrated in the enclosure in each air inlet and outlet.
- Type Designation  
DVE abcdefghij
- The additional letters and digits in the type reference concern different accessories and functions of the instrument.  
a: Air pipe connection thread type, b: Surface treatment, c: Function, d: Spindle, e: Cover and indicator, f: Temperature/Seals, j: Input signal/protocol, k: Feedback option, l: Accessories
- Temperature Class and Range of Ambient Temperatures  
Temperature class T6 -20°C -C145°C  
Temperature class T5 -20°C -C135°C
- Electrical Data  
230V, 24mA
- Ingress Protection Code  
IP 66 according to IEC 60529  
Type 4X according to Nema 250

[16] Report No. 200309114 and the listed Schedule Documents DVE Technical File Contents Rev. C Dated 2003-04-23.

- [17] Special Conditions for Safe Use  
None
- [18] Essential Health and Safety Requirements  
See item 9

This certificate may only be reproduced in its entirety and without any change, schedule included.

Printed address: Oslo, Norway  
Office address: 0375 OSLO  
Telephone: +47 22 96 61 30  
Fax: +47 22 96 61 50  
Enterprise number: NO 174406532

### **D3I:**

D3I - Digital positioner - Intr. safe

EEx ia IIC T4, Ta= -30...+80 C, NEMKO 03ATEX110X



II I GD



0470

INTRINSICALLY SAFE/SECURITE INTRINSIQUE-Exia

When installed in accordance with installation drawing: D3-70

**WARNING!** Substitution of components may impair intrinsic safety.

**AVERTISSEMENT!** La substitution de composants peut compromettre a securite intrinseque.

Serial number, production year, software revision

IP66/Nema 4x

Flowserve, Sweden; Palmstierna International;

S-171 54 Solna; [www.flowserve.com](http://www.flowserve.com)



### [13] Schedule

#### [14] EC-TYPE EXAMINATION CERTIFICATE No Nemko 03ATEX110X

##### [15] Description of Equipment or Protective System

The PMV D31 is a digital pNeiometer designed primarily to control modulating valves. The positioner can be used with single or double action actuators with either rotary or linear movement.

The positioner can be equipped with the following functions:

- electronic board with microprocessor, Hart modem, display etc.
- pneumatic valve block.
- positional feedback with potentiometer

The positioner D31 can also be equipped with modules for feedback, limit switches, and a pressure gauge block. The modules can be factory assembled before delivery or fitted later. The modules for feedback and limit switches can contain the following: Feedback 4-20mA and one of the following functions:

- two mechanical switches: Two reed switches; Two inductive sensors
- Remote unit, an external unit containing the pressure potentiometer and indicator.

##### Type Designation.

##### D31 abcdefghijl

The additional letters and digits in the type reference concern different accessories and functions of the instrument.

- a: Air pipe connection thread type.
- b: Surface treatment.
- c: Function.
- d: Limit switch.
- e: Feedback.
- f: Temperature/Seals.
- j: Input signal/protocol: 4-5 P. The letter 'P' denotes the Profibus version
- l: Limit switch.
- N: Limit sensors NAM + 4-20mA
- P: Limit sensors PXY + 4-20mA
- T: +20mA

##### k: Feedback signal

- X: No accessories
- S: Limit switch MEC + 4-20mA
- N: Limit sensors NAM + 4-20mA
- T: Limit switches PXY + 4-20mA
- L: 20mA transmittance only

##### i: Accessories.

- X: No accessories
- M: Gauge block

##### D31 Remote Unit

A separate unit for connection to the D31

The Remote Unit is connected to terminals 3,4 and 5 on models with type indicator c= C or R and l= L

*This certificate may only be reproduced in its entirety and without any change, schedule included.*

Postal address:	Office address:	Telephone:	Enterprise number:
P.O. Box 73 Blindern	Geitmyrsveien 30	+47 22 96 03 30	NO 97406532
N-0404 OSLO, NORWAY	0657 OSLO	+47 22 96 05 59	



##### Safety Data

The transmitter must be connected to safety barriers or isolators according to the drawing D31-70 and corresponding to the stated input values of the positioner.

##### Profibus PA input signal. Terminals no. 1,2

Maximum input voltage:	U <sub>i</sub> : 15V
Maximum input current:	I <sub>i</sub> : 208mA
Maximum input power:	P <sub>i</sub> : 1.9W
Maximum internal capacitance:	C <sub>i</sub> : 4nF
Maximum internal inductance:	L <sub>i</sub> : 5μH

##### 4-20mA input signal. Terminals no. 1,2

Maximum input voltage:	U <sub>i</sub> : 28V
Maximum input current:	I <sub>i</sub> : 95mA
Maximum input power:	P <sub>i</sub> : 653mW
Maximum internal capacitance:	C <sub>i</sub> : 4nF
Maximum internal inductance:	L <sub>i</sub> : 5μH

##### Switches, Mechanical or Proximity. Terminals 3,5,6,8 or 4,5,7,8

Maximum input voltage:	U <sub>i</sub> : 28V
Maximum input current:	I <sub>i</sub> : 45mA
Maximum input power:	P <sub>i</sub> : 1.26W
Maximum internal capacitance:	C <sub>i</sub> : 4nF
Maximum internal inductance:	L <sub>i</sub> : 5μH

##### Switches, Mechanical or Proximity with isolator barriers. Terminals 3,5,6,8

Maximum input voltage:	U <sub>i</sub> : 10.6V
Maximum input current:	I <sub>i</sub> : 297mA
Maximum input power:	P <sub>i</sub> : 79mW
Maximum internal capacitance:	C <sub>i</sub> : 1nF
Maximum internal inductance:	L <sub>i</sub> : 1μH

##### Namur switch and isolator barrier. Terminals 3-4, 6-7

Maximum input voltage:	U <sub>i</sub> : 10.6V
Maximum input current:	I <sub>i</sub> : 297mA
Maximum input power:	P <sub>i</sub> : 79mW
Maximum internal capacitance:	C <sub>i</sub> : 35nF
Maximum internal inductance:	L <sub>i</sub> : 50μH

*This certificate may only be reproduced in its entirety and without any change, schedule included.*

Postal address:	Office address:	Telephone:	Enterprise number:
P.O. Box 73 Blindern	Geitmyrsveien 30	+47 22 96 03 30	NO 97406532
N-0404 OSLO, NORWAY	0657 OSLO	+47 22 96 05 59	



Nemko 03ATEX110X

Date: 2003-05-07



Page 4 of 5

#### Aux input 4-20mA<sup>1</sup> Terminals 9-10

Maximum input voltage:	28V
Maximum input current:	50mA
Maximum input power:	1.4W
Maximum internal capacitance:	C <sub>i</sub> : 57nF
Maximum internal inductance:	L <sub>i</sub> : 5μH

#### 4-20mA Output Terminals 11-12

Maximum input voltage:	28V
Maximum input current:	70mA
Maximum input power:	572mW
Maximum internal capacitance:	C <sub>i</sub> : 57nF
Maximum internal inductance:	L <sub>i</sub> : 5μH

#### Alarm Terminals 13-14

Maximum input voltage:	28V
Maximum input current:	45mA
Maximum input power:	1.2W
Maximum internal capacitance:	C <sub>i</sub> : 57nF
Maximum internal inductance:	L <sub>i</sub> : 5μH

#### Ambient Temperature Range

-30°C <T<sub>amb</sub> <60°C

D31 Remote Unit  
-30°C <T<sub>ext</sub> <120°C

#### Ingress Protection Code

IP 65 according to IEC 60529  
Type 4X according to NEMA 250

[16] Report No. 200309115 and the list of Schedule Documents D31 Technical File Contents Rev. B Dated 2003-05-06.

*This certificate may only be reproduced in its entirety and without any change, schedule included.*

Printed address: P.O.Box 73 Blindern  
N-0404 OSLO, NORWAY  
Office address: Gamstveien 30  
0375 OSLO  
Telephone: +47 22 96 03 30  
+47 22 96 05 59  
Enterprise number: NO 974404532



Nemko 03ATEX110X

Date: 2003-05-07




Page 5 of 5

#### [17] Special Conditions for Safe Use

1. The enclosure is made of aluminium and impact or friction caused by external objects shall be avoided in the application.
2. The surface area of the plastic parts on the cover exceeds the limits specified in EN 50284 for gas group IIC and intensive rubbing or brush charging should be avoided when used in an IIC explosive atmosphere.

#### [18] Essential Health and Safety Requirements


See item 9



*This certificate may only be reproduced in its entirety and without any change, schedule included.*


Printed address: P.O.Box 73 Blindern  
N-0404 OSLO, NORWAY  
Office address: Gamstveien 30  
0375 OSLO  
Telephone: +47 22 96 03 30  
+47 22 96 05 59  
Enterprise number: NO 974404532

# 11. Spare parts





Pos	Part no.	Description
1	D3-SP6	Cover incl.screws
2	D3-SP11	Internal cover incl.screws
3	P3-SP13	Cover plate incl. screws
4	P5-Sxx	Spindle adapter
5	D3-SP1	Block compl incl. cable, rubber seal, filter-plug
6	D3-SP9	Filter-plug incl. O-ring, filter
7	D3-SP8	Potentiometer compl incl. spring, holder, cable
8	D3-SP8-270	Potentiometer compl incl. spring, holder, cable, 270deg
9	D3-SP20	Shaft compl incl. gearwheel, friction clutch
10	D3-SP20-270	Shaft compl.incl. gearwheel, friction clutch, 270deg
11	D3-SP37	Pcb display assy
12	D3-SP80X	PCBs (terminal and processor)
13	D3-SP80H	PCBs (terminal and processor) HART
14	D3-SP35I	PCBs (terminal and processor) intrinsically safe
15	D3-SP35IH	PCBs (terminal and processor)intrinsically safe, HART
16	D3-SP35PF	PCBs (terminal and processor) Profibus/Fieldbus
17	P4A8	Arrow pointer
18	D3-SP/SCREW	Kit, bag with screws
19	D3-SP/SEAL	Kit, bag with O-rings, seals
20	D3-SP42	Cables and PC boards to pneumatic block
21	D3-SP34G	Gaugeblock G, complete
22	D3-SP34N	Gaugeblock N, complete
23	D3-AS38M	Transmitter board, Mechanical switches, assy +420
24	D3-AS38N	Transmitter board, Namur sensors, assy +420
25	D3-AS38P	Transmitter board, Proximity switches, assy +420
26	D3-AS38T	Transmitter board 4-20, assy
30	D3-SP6WC	Cover incl. screws, Worcester
31	D3-67	Silencer



<b>Pos</b>	<b>Part no.</b>	<b>Description</b>
1	D3E-SP2	Front cover incl. screw
2	D3E-SP3	Terminal cover incl. screw
3	D3E-SP4	Internal cover incl. screws
4	P5-Sxx	Spindle adapter
5	D3-SP1	Block compl. incl. cable, rubber seal, filter-plug
6	D3-SP9	Filter plug incl.O-ring, filter
7	D3E-SP8	Potentiometer compl. incl. spring, holder, cable
8	D3E-SP8-270	Potentiometer compl. incl. spring, holder, cable
9	D3E-SP20	Shaft compl. incl. gearwheel, friction clutch
10	D3E-SP20-270	Shaft compl. incl. gearwheel, friction clutch
11	D3-SP37	Display pcb
12	D3E-SP35X	All PCB's, (processor, mother, terminal)
13	D3E-SP35H	All PCB's, HART, (processor, mother, terminal)
14	D3E-SP40	Terminal PCB
15	D3E-SP/Screw	Kit with screws D3E
16	D3E-SP/Seal	Kit with O-rings
17	D3E-SP42	Cable for pneumatic block, incl. 2 x PCB



**Palmstierna International AB**

Korta Gatan 9

SE-171 54 Solna

SWEDEN

Tel: +46 (0) 8 555 106 00

Fax: +46 (0) 8 555 106 01

E-mail: [infopmv@flowserve.com](mailto:infopmv@flowserve.com)

Internet: [www.pmv.nu](http://www.pmv.nu)

---

**Flowserve**

Manderscheidtstrasse 19

45141 Essen

GERMANY

Tel: +49 (0) 201 8919 5

Fax: +49 (0) 201 8919 662

**Flowserve**

12, av. du Québec

91965 Courtaboeuf Cedex

FRANCE

Tel: +33 (0) 1 60 923 251

Fax: +33 (0) 1 60 923 299

**Flowserve**

Van Leeuwenhoekweg 6

3225 LX Hellevoetsluis

THE NETHERLANDS

Tel: +31 (0) 181330044

Fax: +31 (0) 181330040

**Flowserve**

Kassemengasse 6

9500 Villach

AUSTRIA

Tel: +43 (0) 424241 181-0

Fax: +43 (0) 424241 181 50/51

**Flowserve**

Allée du Quartz 1

CH-2300 La-Chaux-de Fonds

SWITZERLAND

Tel: +41 (0) 32 925 9700

Fax: +41 (0) 32 926 5422

**Flowserve**

Via Prealpi, 30

Cormano (Milano)

ITALY

Tel: +39 (0) 2663251

Fax: +39 (0) 26151863

**Flowserve**

Av. Dr. Antunes Guimaraes 1159

Porto 4100-082

PORTUGAL

Tel: +351 22 619 8770

Fax: +351 22 619 7575

**Flowserve**

1350 N. Mt. Springs Prkwy.

Springville, UT 84663

USA

Tel: +1 801 489 8611

Fax: +1 801 489 3719

**Flowserve**

Post box 9279

Edenglen 1613

SOUTH AFRICA

Tel: +27 11 923 7300

Fax: +27 11 974 6127

**Flowserve**

12 Tuas Avenue 20

REPUBLIC OF

SINGAPORE 638824

Tel: +65 862 3332

Fax: +65 862 4940

**Flowserve**

C/O Saleh &

Abdulaziz Abahsain

P.O. Box 209

Al Khobar 31952

SAUDI ARABIA

Tel: 9663 857 3442

Fax: 9663 859 5284